

Service

Electrical Wiring Diagrams

90

USA/Canada m.y. 1993

This publication contains electrical wiring diagrams for the Audi 90, model year 1993, sold in the USA and Canada. Whenever working on Audi vehicles, follow the procedures described on the appropriate Repair Manual Microfiche. Use of tools or procedures other than those recommended may be detrimental to the safe operation of the vehicle as well as the safety of the person doing the repair.

Before working on any car, read Warnings and Cautions.

**©Audi of America, Inc.
Technical Service Communications
Printed 9/94
W42 WD BOOK AU 04**

All rights reserved. All information contained in this manual is based on the latest product information available at the time of printing. The right is reserved to make changes at any time without notice. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

General

Cautions and warnings	i
How to read wiring diagrams	iii
Standard circuit/terminal designations	vi
Standard wire/connector designations	vii
Symbols used in wiring diagrams.....	iv
Test equipment	viii
Troubleshooting procedure	xvi
Wiring harness repairs	xv

90-All Models (Up to VIN: 8 CPA 000100) USA/Canada

ABS combi relay (2-wheel drive system)	43
ABS Control Module (2-wheel drive system)	41
ABS Quattro (with rear differential lock)	63
Airbag triggering unit	55
AM/FM stereo radio (anti-theft) with 6-speakers	69
Ashtray lights	49
Auto check system	25
Automatic climate control	73
Automatic transmission and cruise control (2-wheel drive)	85
Auxiliary/relay panel, rear	7
Auxiliary relay panel with connector station	6
Back-up light switch	40
Brake light switch	40
Central locking system	45
Cigarette lighters	48
Connections and plugs on fuse/relay panel, rear	9
Connector identification on connector station	8
Cruise control, Control Module	44
Daytime running lights (Canada only)	97
Digital clock	27
Dual horns	39
ECM (Engine Control Module)	19
8-Way power front driver's seat (w/o memory)	60
Emergency flasher relay	37
Emergency switch	37
Engine compartment light	35
Engine oil pressure sensor	57
Engine oil temperature sensor	57
Fuse panel	34
Fuse/relay panel	1
Generator (GEN)	17
Glove compartment light	35
Heated door locks	105
Heated front seats	107
Ignition/starter switch	31
Instrument cluster	29
Interior lights	50
Lamp Control Module, front	32
Lamp Control Module, rear	33
Main wiring diagram index	10
Manual air conditioning	109
Mini-check system	118
Mirror adjustment switch	54

**90-All Models
(Up to VIN: 8 CPA 000100)
USA/Canada
(Continued)**

Power window Control Module	51
Power windows	53
Reading lights	50
Seat belt warning Control Module	36
Servotronic Control Module	56
Starter	17
Tilt and slide power sunroof	128
Windshield wiper intermittent switch	38

**90-All Models
(From VIN: 8 CPA 000100)
USA/Canada**

ABS Control Module	157
ABS Quattro	165
Airbag Control Module	153
AM/FM stereo radio with 6-speakers	171
Auto check system	142
Automatic climate control (Automatic transmission)	176
Automatic climate control (Manual transmission)	183
Automatic transmission	189
Auxiliary/relay panel, rear	132
Auxiliary relay panel with connector station	132
Battery	134
Central locking system	151
Cruise control, Control Module	158
Daytime running lights (Canada only)	195
ECM (Engine Control Module)	135
8-Way power front driver's seat (w/o memory) .	162
Engine compartment light	146
Emergency flasher relay	147
Emergency flasher switch	147
Engine oil pressure sensor	160
Engine oil temperature sensor	160
Fog lights	149
Fuel pump	138
Fuse/relay panel	131
Generator	134
Glove compartment light	146
Ground connectors	133
Heated door locks	202
Heated front seats	205
Ignition/starter switch	139
Instrument cluster	140
Interior lights	150
Lamp Control Module, front	144
Lamp Control Module, rear	143
Light switch	145

**90-All Models
(From VIN: 8 CPA 000100)
USA/Canada
(Continued)**


Manual air conditioning (Manual transmission)	210
Mini-check system	215
Mirror adjustment switch	154
Power sunroof	220
Power windows	156
Power windows Control Module	155
Radio	159
Reading lights	150
Servotronic Control Module	157
Starter	134
Windshield wiper intermittent switch	148


Please read these **WARNINGS** and **CAUTIONS** before proceeding with maintenance and repair work.

- If you lack the skills, tools and equipment, or a suitable workshop for any procedure described in this manual, we suggest you leave such repairs to an authorized Audi dealer or other qualified shop. We especially urge you to consult an authorized Audi dealer before beginning repairs on any car that may still be covered wholly or in part by any of the extensive warranties issued by Audi.
- Audi is constantly improving its cars and sometimes these changes, both in parts and specifications, are made applicable to earlier models. Therefore, part numbers listed in this manual are for reference only. Always check with your authorized Audi dealer parts department for the latest information.
- Never work under a lifted car unless it is solidly supported on stands designed for this purpose. Do not support a car on cinder blocks, hollow tiles or other props that may crumble under continuous load. Never work under a car that is supported solely by a jack. Never work under the car while the engine is running.
- If you are going to work under a car on the ground, make sure that the ground is level. Block the wheels to keep the car from rolling. Disconnect the battery Ground (GND) strap to prevent others from starting the car while you are under it.
- Never run the engine unless the work area is well ventilated. Carbon monoxide kills.
- Tie long hair behind your head. Do not wear a necktie, a scarf, loose clothing, or a necklace when you work near machine tools or running engines. If your hair, clothing, or jewelry were to get caught in the machinery, severe injury could result.
- Illuminate the work area adequately but safely. Use a portable safety light for working inside or under the car. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.
- Finger rings should be removed so that they cannot cause electrical shorts, get caught in running machinery, or be crushed by heavy parts.
- Disconnect the battery Ground (GND) strap whenever you work on the fuel system or the electrical system. Do not smoke or work near heaters or other fire hazards. Keep an approved fire extinguisher handy.
- Any time the battery has been disconnected it will be necessary to reestablish Basic Settings for the Engine Control Module (ECM) and, on vehicles with automatic transmissions, the Transmission Control Module (TCM), using the VAG 1551 Scan Tool (ST).
- On cars equipped with anti-theft radios, make sure you know the correct radio activation code before disconnecting the battery or removing the radio. If the wrong code is entered into the radio when power is restored, that radio may lock up and be rendered inoperable, even if the correct code is then entered.
- Do not attempt to work on your vehicle if you do not feel well. You increase the danger of injury to yourself and others if you are tired, upset or have taken medicine or any other substance that may impair you from being fully alert.
- Always observe good workshop practices. Wear goggles when you operate machine tools or work with battery acid. Gloves or other protective clothing should be worn whenever the job requires working with harmful substances.
- Do not re-use any fasteners that are worn or deformed in normal use. Many fasteners are designed to be used only once and become unreliable and may fail when used a second time. This includes, but is not limited to, nuts, bolts, washers, self-locking nuts or bolts, circlips, cotter pins. Always follow recommendations given in this publication. Always replace these fasteners with new parts.
- Friction materials such as brake pads and clutch discs may contain asbestos fibers. Do not create dust by grinding, sanding, or by cleaning with compressed air. Avoid breathing asbestos fibers and asbestos dust. Breathing asbestos can cause serious diseases such as asbestosis or cancer, and may result in death.





























Please read these WARNINGS and CAUTIONS before proceeding with maintenance and repair work.

- Catch draining fuel, oil or brake fluid in suitable containers. Do not use empty food or beverage containers that might mislead someone into drinking from them. Store flammable fluids away from fire hazards. Wipe up spills at once, but do not store the oily rags, which can ignite and burn spontaneously.
- Keep sparks, lighted matches, and open flame away from the top of the battery. If escaping hydrogen gas is ignited, it will ignite gas trapped in the cells and cause the battery to explode.
- The air-conditioning (A/C) system is filled with a chemical refrigerant that is hazardous. The A/C system should be serviced only by trained technicians using approved refrigerant recovery/recycling equipment, trained in related safety precautions, and familiar with regulations governing the discharging and disposal of automotive chemical refrigerants.
- Do not expose any part of the A/C system to high temperatures such as open flame. Excessive heat will increase system pressure and may cause the system to burst.
- Some of the vehicles covered by this manual are equipped with a supplemental restraint system (SRS), that automatically deploys an airbag in the event of a frontal impact. The airbag is operated by an explosive device. Handled improperly or without adequate safeguards, it can be accidentally activated and cause serious personal injury. To guard against personal injury or airbag system failure, only trained Audi Service technicians should test, disassemble or service the airbag system.
- Never use a test light to conduct electrical tests on the airbag system. The system must only be tested by trained Audi Service technicians using the Audi VAG 1551 Scan Tool (ST) or an approved equivalent. The airbag unit must never be electrically tested while it is not installed in the vehicle.
- Before starting a job, make certain that you have all the necessary tools and parts on hand. Read all the instructions thoroughly, do not attempt shortcuts. Use tools appropriate to the work and use only replacement parts meeting Audi specifications. Makeshift tools, parts and procedures will not make good repairs.
- Use pneumatic and electric tools only to loosen threaded parts and fasteners, especially on light alloy parts. Always use a torque wrench to tighten fasteners to the tightening torque listed.
- Be mindful of the environment and ecology. Before you drain the crankcase, find out the proper way to dispose of the oil. Do not pour oil onto the ground, down a drain, or into a stream, pond or lake. Consult local ordinances that govern the disposal of wastes.
- Before doing any electrical welding on vehicles equipped with ABS, disconnect the battery Ground (GND) strap and the ABS Control Module connector.
- When boost charging the battery, first remove the fuses for the Engine Control Module (ECM), Transmission Control Module (TCM), ABS Control Module, and the On-Board computer. In cases where one or more of these components is not separately fused, disconnect the Control Module connector(s).
- Do not quick-charge the battery (for boost starting) for longer than one minute, and do not exceed 16.5 Volts at the battery with the boosting cables attached. Wait at least one minute before boosting the battery a second time.
- Some aerosol tire inflators are highly flammable. Be extremely cautious when repairing a tire that may have been inflated using an aerosol tire inflator. Keep sparks, open flame or other sources of ignition away from the tire repair area. Inflate and deflate the tire at least four times before breaking the bead from the rim. Completely remove the tire from the rim before attempting any repair.





97-2429

	Resistance		Cigarette lighter
	Diode		Rear window defogger heat element
	Zener diode		Horn
	LED		Push-on connector
	Instrument (Gauge)		Multi-point connector on component
	Electronic Control Module		Wiring junction
	Analog clock		Wiring connection, detachable
	Digital clock		Wiring connection, fixed
	Multi-function indicator		Internal connection in a component
	Buzzer		Resistance wire
	Consumption indicator		Control motor, headlight range adjustment
	Speed sensor		Crankshaft Position (CKP) sensor
	Light bulb		Slip contact
	Light bulb (dual-filament)		
	Interior light		

Standard Circuit/terminal Designations

Circuit Number	Circuit Description	Most Common Wire Color
15	Powered when ignition switch is in "On" or "Start" positions	Black (BK)
x	Load-reduction circuit Powered by load-reduction relay when ignition switch in in "On" position (Not powered in "Start" position)	Black/Yellow (BK/Y)
30	Battery positive (+) Voltage Powered whenever battery is connected	Red (R)
31	Ground (GND) or battery negative (-)	Brown (BR)
50	Powered only when ignition switch is in "Start" position	Red/Black (R/BK)
B+	From generator (GEN) Charging Voltage to battery	Red (R)
D+	Generator (GEN) warning light and field energizing circuit	—
85	Ground (GND) (-) side of switching relay	Brown (BR)
86	Power-input (+) side of switching relay	—
87	Relay change-over contact	—

Wire Color-Code

BK	Black
BL	Blue
BR	Brown
CL	Clear
G	Green
GY	Gray
LT.G	Light Green
OR	Orange
R	Red
V	Violet
W	White
Y	Yellow

Combined codes indicate a multi-colored wire.

Example: The code R/G indicates a red wire with a green tracer stripe.

Note

Sometimes the wire color on the car may be different than the one on the wiring diagram. Don't be concerned, just be sure to confirm that the wires connect to the proper terminals.

Wire Size

The wiring diagrams in this manual identify wires by their metric wire size. Metric wire sizes indicate cross-sectional area in square millimeters (mm²). The table below lists metric wire sizes and their equivalents in American Wire Gauge (AWG) sizes.


Metric size (Cross-sectional area-mm ²)	American Wire Gauge (AWG)
0.35	22
0.5	20
0.75	18
1.0	16
1.5	14
2.5	12
4.0	10
6.0	8
16.0	4
25.0	2
35.0	2

Connectors

T1	Single-point
T2	2-point
T3	3-point
T4	4-point
T6	6-point
T8	8-point
T10	10-point
T12	12-point
T26	26-point

Each connector has a unique number. Example: T6, T6a and T6b are three different 6-point connectors.

Wiring diagrams usually also identify a particular connector terminal. Example: T3a/2 is terminal two of connector T3a.



2. Test Equipment

Special Tools

The most basic electrical troubleshooting calls for specialized electrical test equipment. Dealer Service Department technicians do this work using Special Tools, many of which are designed specifically for working on electrical systems.

Proper tools are essential to ensure accurate test results and to prevent damage to sensitive components.

The Special Tools shown in this manual are identified by the order numbers that can be used to special-order the tools through your authorized dealer Parts Department.

2.1 LED Test Light

A test light is an inexpensive tool used to perform many simple electrical tests that would otherwise require a multimeter. It lights to indicate when there is Voltage potential between any two test-points in a circuit.

With one probe contacting the battery negative (–) terminal or a known ground (GND) connection, the other probe can be used to check for Voltage at other points in the circuit. The test light will light when the test probe contacts a Voltage source, and current flows from the Voltage source to ground (GND).

With one probe contacting a known source of Voltage, the other probe can be used to check for continuity to ground (GND) at other points in the circuit. Current will flow and the test light will light when the test-point provides the known Voltage source with a path to ground (GND).

Caution

A common test light (with incandescent bulb) may no longer be used. The bulb's high current draw will damage sensitive electronic components.


LED Test Light (US 1115)

Used to check for Voltage reaching components or when searching for malfunctions in a circuit.

Voltage range: 3 to 48 VDC

CAUTION

A common test light (with incandescent bulb) may no longer be used. The bulb's high current draw will damage sensitive electronic components.



Note

This tool has been superseded by Special Tool VAG 1527B, LED Tester. (US 1115 is still considered an acceptable equivalent to VAG 1527B).

LED Tester (VAG 1527B)

Order Number: TAG 152 7B0 28 ZEL

Two-pole Voltage tester with two LEDs (light emitting diodes), suitable for measuring from 3 to 48 Volts DC or AC.

When used to test DC circuits, the positive (+) or negative (-) LED will light, depending on polarity. When used to test AC circuits, both LEDs will light.


Supplied with banana clip and detachable probe-can be used directly with VAG 1598 Test Box.

For troubleshooting all common electrical and electronic components in automobiles. Safe for testing electronic components and circuits because of extremely low current consumption (1.5 mA maximum).

Voltage range: 3 to 48 Volts (AC or DC)

CAUTION

A common test light (with incandescent bulb) may no longer be used. The bulb's high current draw will damage sensitive electronic components.




Note

This tool supersedes Special Tool US 1115 LED Test Light.

Making an LED Test Light

A lower-cost alternative to buying an LED Test Light such as US 1115 or VAG 1527B is to make one, using parts available from most any electronics supply outlet.

Assemble the components as shown. Use needle nose pliers to hold the parts and to act as a heat dam while soldering. Insulate the connections with heat-shrinkable tubing or electrical tape.



Do-it-yourself LED Test Light for safely testing sensitive solid-state circuits.

Parts:

1. LED (1)
2. 1/4 watt, 330 Ω resistor (1)
3. Alligator clips (2)
4. Wire, Solder and Soldering Iron
5. Heat-shrinkable tubing or electrical tape

2.2 Multimeter or Volt/Ohm Meter (VOM)

A multimeter or Volt-Ohm meter (VOM) is used to measure Voltage, resistance (Ohms) or current (amps or millamps). Two types of meters are in common use. The analog or swing-needle Volt-Ohm meter displays test values according to the position of a needle on the meter face. A digital multimeter displays test values as numbers. The meters shown here and recommended are digital multimeters.

Accuracy is an important consideration when choosing a meter. Analog or swing-needle Voltmeters are generally rated for accuracy as a percentage of full-scale on the meter face. A typical analog meter may be rated as accurate to $\pm 3\%$ of full scale. Some analog meters offer 10-Volt and 50-Volt scales, with no range in between. For 12-Volt automotive electrical systems, this means testing on the 50-Volt scale, with a corresponding decrease in accuracy. On a 50-Volt scale, $\pm 3\%$ accuracy is equal to ± 1.5 Volts. While still useful for testing circuits such as lights and horns, analog meters may not be accurate enough for use where precise measurements are required.

Digital multimeters are preferred for precise measurement and for electronics work because most digital multimeters are more accurate than most analog meters. Another advantage of digital multimeters is that they are less likely to be misread, since there is no needle position to be misinterpreted or distorted by reading at an angle.

Perhaps the most important consideration is input impedance-how much of a load the meter places on the circuit being tested. Meters with low input impedance place a greater load on the circuit because they allow more current flow through the meter. This can exceed design limits and be damaging to sensitive electronic components.

Most digital multimeters have very high input impedance-10 megohms (10,000,000 Ω) or higher-and make their measurements while allowing very little current flow through the meter. The meter itself is not a load in the circuit, and does not induce damaging current flow.

Multimeter Kit - digital (US 1119, VAG 1526)
Order Number: TU1 119 000 00 KTM

Used for monitoring electronic engine controls (Example: setting/checking the idle speed control system) and for general electrical troubleshooting.




Note

This tool has been superseded by the Fluke 83® Digital Multimeter. (US 1119 or VAG 1526 are still considered acceptable equivalents).

Fluke 83® Digital Multimeter
Order Number: TFL UKE 830 00 RSE

Used for monitoring electronic engine controls (Example: setting/checking the idle speed control system) and for general electrical troubleshooting.

- 10 Megohm input impedance
- ± 0.3% DC Voltage accuracy
- fully overload-protected



Note

This tool supersedes Special Tool US 1119 Digital Multimeter Kit.

2.3 Test Kits

Adaptor Kit (VW 1594)
Order Number: TV1 594 400 97 KTM

Used to connect electrical measuring equipment to various harness connectors in the electrical system.


CAUTION

Test connections made carelessly or without proper tools can damage harness connectors, causing poor connections and future problems.




Test Box (VAG 1598)
Order Number: WAG 159 800 00 VOA

Used to perform static and dynamic tests of electrical and electronic systems without damaging miniature contacts, especially where limited access to connectors makes testing difficult.



Tester (VAG 1466)

Used to systematically troubleshoot electrical circuits.




2.4 Computer Memory Saver

Used on vehicles with theft-protected radios to prevent the radio from electronically locking when battery power is disconnected. Use of this tool eliminates the need to re-activate the radio (reenter the correct code) after reconnecting battery power.


WARNING

Always separate the airbag Voltage supply connector before using a computer memory saver. Failure to do so may result in accidental activation of the airbag. For more information, see the Circuit Section in this manual entitled Airbag, or see the Repair Manual.



Snap-On
Computer Memory Saver
Part No. YA960

91-A051



Home-made computer memory saver

91-A052


3. Handling Components and Connectors

Harness Connectors

The harness connectors used throughout the vehicle are designed to positively lock into place. Press on wire lock as shown to release the connector.

CAUTION

To disconnect, pull only on the connector body. Never pull on the wires themselves.




Typical wiring harness connector. Push on wire lock (arrow) and gently pull on connector to release.

Making Test Connections

Many electrical troubleshooting tests will require hooking up to wiring harness connectors, or socket connectors on electrical components. Test connections made carelessly or without proper tools can easily damage the connectors, causing poor connections and future problems.

To avoid connector damage, test connections to wiring harness connectors must be made using small, flat-blade terminals which will mate properly with the connectors. The Special Tools recommended include special adapters which can be used to make test connections safely and prevent connector damage. See 2. **Test Equipment.**

All test connections to harness connectors should be made using the proper adapter or correct size flat connectors that will not deform the connector cavities.




*Alligator-clip test leads with flat connectors
(Part Number: N 17 457 2)*


Wiring Harness Repairs

When repairing wiring harnesses, use only high-quality electrical connectors suitable for use with electronic components.


To make connections, use crimping pliers that make a "W"-type crimp. Only this type of crimp provides the necessary mechanical strength.



Typical "W"-type crimp connection



Typical wire crimping pliers, not suitable for making "W"-type crimps.



Wire crimping pliers, used to make "W"-type crimps.

Connector repair kits, connectors and the correct crimping pliers are available through your authorized dealer Parts Department.

4. Troubleshooting

4.1 Basic Electricity

Electricity is defined by three basic elements: Voltage, Current and Resistance.

Voltage

Voltage is a measure of electromotive force, sometimes referred to as electrical "pressure". It can be described as the difference in potential (potential for the flow of electricity) between any two points in a circuit.

A typical automobile battery, for example, has a difference in potential of about 12 Volts between the positive (+) terminal and the negative (-) terminal.

The basic units of electrical potential are **Volts (V)**. Very low Voltages are expressed as **millivolts (mV)**.
1 V = 1000 mV; 1 mV = .001 V

Current

Current is the term describing the flow of electricity through a conductor. In a complete circuit, potential (Voltage) will cause current to flow from positive (+) to negative (-).

The basic units of current flow are amperes or **amps (A)**. Small amounts of current flow are often measured in **millamps (mA)**.
1 A = 1000 mA; 1 mA = .001 A

Resistance

Resistance resists or opposes the flow of electricity. Conductors are made from materials of low resistance that allow electricity to flow easily. Insulators are materials of very high resistance that inhibit the flow of electricity.

The basic unit of resistance is the **Ohm Ω** . High resistance values are often expressed as Kilohms (K Ω).
1 K Ω = 1000 Ω

Resistance vs. Current Flow

The basic rule of electricity (Ohm's Law) states that one unit of force (1 Volt) is required for one unit of current (1 am) to flow against one unit of resistance (1 Ohm). From Ohm's Law, we also know that:

$$\text{Voltage} = \text{Current} \times \text{Resistance}$$

When Voltage is approximately constant, as in an automobile electrical system, current and resistance affect each other. As resistance increases, there will be less current flow. And lower resistance will permit higher current flow.

Higher resistance = lower current flow

Example: Corrosion on a headlight connector (higher resistance) causes the light to be dim (lower current flow).


Lower resistance = higher current flow

Example: A damaged wire shorted to ground (GND) (lower resistance) overloads circuit capacity (higher current flow) and blows a fuse.

Definition of a Circuit

Four things are required for current to flow in any electrical circuit, and for that circuit, and for that circuit to function as intended:

- **Power Source (Voltage)**
- **Conductors** (wires, printed circuits, etc.)
- **Load or Consumer** (a user of electrical power)
- **Complete Circuit** (a connection to ground [GND])



A complete circuit

Open Circuits

An open circuit is an incomplete circuit. An open circuit occurs when some kind of malfunction interrupts the circuit path and prevents current flow. Some common causes of open circuits are:

- broken wire
- loose or disconnected connector
- loose or damaged connector terminal
- corrosion
- malfunctioning fuse or component

Test for an open circuit by checking continuity using an Ohmmeter (multimeter), or by checking for Voltage at various points of the circuit using a test light or Voltmeter (multimeter). See 4.4 **Checking Wiring and Components**.

Short Circuits

A short circuit is an unintended complete circuit. A short circuit occurs when some kind of malfunction causes current flow to follow the wrong path.

A short circuit to ground (GND) (grounded circuit) may prevent Voltage from reaching a component. If Voltage is shorted directly to ground (GND), bypassing any load, the unrestricted current flow will damage fuses wires or components. Some common causes of short circuits are:

- damaged wire or wiring harness
- malfunctioning insulation
- internally damaged component
- incorrect connection

Test for a short circuit to ground (GND) using a multimeter or a test light to indicate circuit malfunctions and abnormal current flow paths. See 4.5 **Checking for Short Circuit to Ground (GND)**.

Troubleshooting Procedure

Verify the complaint – Check the complaint. Try to understand the problem. If possible, let the driver show you what happens. Check all functions of the system and note the symptoms before starting any testing or disassembly.

Analyze the problem – Identify the part of the electrical system that is most likely to be causing the problem. Find the Circuit Section in the manual that applies to that part of the system. Find the wiring diagram that applies to the vehicle. By following the circuit from a ground (GND) back to the power source, get an understanding of how the circuit works.

Find the problem – You will find the problem if you follow a simple and logical step-by-step procedure. Test portions of the circuit one at a time, starting with the area or component most likely to be malfunctioning. Test first at points that you can reach most easily.

Repair the problem – When you find the cause of the problem, make the repair. Use appropriate tools and procedures.

Check the results – Be sure it works. Check the functions of all parts of the circuit that you worked on.

Working on the Electrical System

A test light or a multimeter can be very helpful for testing circuits. See 2. **Test Equipment** for more information on test equipment.

Current flow is logical, always moving from the highest potential at the Voltage source (+) toward the lowest potential at ground (–). Using a wiring diagram to trace a circuit, you should start with the ground (GND) and then follow the wires back to the source of power.

To troubleshoot a circuit:

1. Inspect all connections, especially grounds (GND). Make sure they are clean, tight and corrosion-free.
2. Check the fuses.

Note

Repeated fuse failures are the sign of a malfunctioning wire, a failed component, or a short to ground (GND) somewhere in the circuit.

3. Check for Voltage reaching particular components or points in the circuit.
4. Check continuity between points to look for breaks in the circuit (open circuit).
5. Check Voltage drop at connections, especially ground (GND) connections.

4.2 Checking for voltage

Checking for Voltage confirms that the circuit is uninterrupted between the Voltage source and the test point. The example illustrates troubleshooting the high-speed circuit for the radiator cooling fan.

Voltage: If the test light or multimeter indicates Voltage potential, then the circuit between the Voltage source and terminal 1 of the fan connector is OK.



NO Voltage: Power is not reaching the fan connector. The fan is probably OK. Look for a malfunction somewhere between the Voltage source and the fan connector.

(Example: Check for Voltage reaching terminal E87La of the fuse/relay panel)

CAUTION

Direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.

Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.





4.3 Checking Ground (GND) Connections

Checking ground (GND) connections as shown confirms that the circuit is complete - that the necessary path to ground (GND) is uninterrupted and current can flow in the circuit. The example illustrates troubleshooting the high-speed circuit for the radiator cooling fan.


Voltage: If the test light or multimeter indicates Voltage, then there is potential for current flow between the known Voltage source and ground (GND) at the test point. The ground (GND) side of the circuit, between terminal 3 of the fan connector and battery negative (-), is OK.

NO Voltage: The test point is not providing a path that completes the circuit to ground (GND). The fan is probably OK. Look for a malfunction somewhere in the wiring between the fan connector and chassis ground (GND). Also check the mechanical ground connection at the chassis (body).



Continuity (approximately 0 Ω): Little or no resistance indicates that there is a continuous conductive path between the two test points - the circuit's ground (GND) path between terminal 3 and battery negative (-) is OK.


No Continuity: There is resistance to current flow in the ground (GND) side of the circuit. The fan is probably OK. Look for a malfunction somewhere in the wiring between the fan connector and chassis ground (GND). Also check the mechanical ground (GND) connection at the chassis (body).



CAUTION

direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.


Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.



4.4 Checking Wiring and Components

Resistance or Continuity

Checking a portion of the wiring harness or a component as shown indicates whether or not there is a continuous conductive path - whether current can flow between the two test points. The example illustrates troubleshooting the Close Throttle Position switch and the Wide Open Throttle Position switch in the fuel injection system.



CAUTION


Resistance measurements and continuity checks must always be made with all power to the circuit or component switched OFF. When testing continuity in a circuit that is always powered (fuse/relay panel "30" circuit for example) disconnect the battery before testing.

Always use a digital (low current) meter. An ohmmeter, or the Ohms scale of a multimeter, measures resistance by passing a small amount of current through the circuit or component being checked.

Improper testing may damage sensitive electronic components.

Continuity (approximately 0 Ω): Little or no resistance indicates that there is a continuous conductive path between the two test points. As shown, this is correct for the normally Closed Throttle Position switch in the Closed Throttle Position (switch not actuated). Also check that the switch opens (no continuity) when actuated by the throttle.

No Continuity: There is resistance to current flow through the switch. In the example, this indicates that the normally Closed Throttle Position switch or the wires between it and the connector (t3) are malfunctioning.




CAUTION

Direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.

Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.

Continuity (approximately 0 Ω): Little or no resistance indicates that there is a continuous conductive path between the two test points. In the example, this indicates that the normally Wide Open Throttle Position switch is malfunctioning.

No Continuity: There is no connection—an open circuit. As shown, this is correct for the normally Wide Open Throttle Position switch. Also check that the switch closes, completing the circuit, when actuated by the Wide Open Throttle Position switch.



Voltage Drop

Checking Voltage drop across connections or components as shown will indicate whether there is abnormal resistance creating an additional load in the circuit - consuming power and dropping the Voltage available to other parts of the circuit.

Note

Voltage drop measurements can only be made when the circuit is powered and there is normal current flow.

The example illustrates troubleshooting the back-up light switch. The switch is in the circuit to switch power to the back-up lights On and Off. When Reverse gear is selected and the switch is closed, it should have very little resistance and not be a consumer.

If dirt or corrosion on the switch contacts creates resistance, some of the available battery Voltage goes into overcoming that resistance. Less Voltage is available to light the back-up lights, and they will not be as bright.

Note

An ohmmeter can measure resistance (or check continuity) only when the circuit is not powered, i.e. when there is almost no load.

CAUTION

Direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.


Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.

Low Voltage: A low Voltage reading across the two switch contacts indicates almost no difference in potential. Resistance across the switch is low - most of the battery Voltage is passing through the switch and is still available to power the lights.

High Voltage: Any significant Voltage reading indicates a difference in potential across the switch contacts. Excessive resistance is loading the circuit, causing a Voltage drop - Voltage is consumed overcoming the resistance of the switch, and less is left to power the lights.

Maximum allowable Voltage drops recommended by the Society of Automotive Engineers are:

- 0.0 Volt for small wire connections
- 0.1 Volt for high current connections (example: fuel pump, headlights)
- 0.1 Volt for ground (GND) connections
- 0.2 Volt for high-current cables (example: battery/starter cable)
- 0.3 Volt for switch or relay contacts



4.5 Checking for Short Circuit to Ground (GND)

Checking the circuit as shown will detect circuit malfunctions that are providing an unintended current flow path to ground (GND). The examples illustrate two methods of troubleshooting a short to ground (GND) that is causing a blown fuse in the circuit powering the license plate lights and the glove compartment light.

Using an Ohmmeter (Multimeter)

Step 1 - Remove the fuse

Step 2 - Disconnect the load (powered components) to eliminate the circuit's normal path to ground (GND)

CAUTION

Always use a digital (low current) meter. An ohmmeter, or the Ohms scale of a multimeter, measures resistance by passing a small amount of current through the circuit or component being checked. Improper testing may damage sensitive electronic components.


Continuity (approximately 0 Ω): Little or no resistance indicates that there is a continuous conductive path between the isolated circuit and ground (GND), even though all the circuit's normal ground (GND) paths are eliminated. There is a short - an unintentional connection to ground (GND) - somewhere in the circuit.

No Continuity: The circuit's normal ground (GND) paths have been disconnected, and there is no other connection between the isolated circuit and ground (GND) - no short has been detected.

CAUTION

Direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.

Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.



Using an LED Test Light or Voltmeter (Multimeter)

Step 1 - Remove the fuse

Step 2 - Disconnect the load (powered components) to eliminate the circuit's normal path to ground (GND)


Voltage: If the test light or multimeter indicates Voltage, then there is a complete circuit - a connection to ground (GND) even though all the circuit's Normal ground (GND) paths are eliminated. There is a short - an unintentional connection to ground (GND) - somewhere in the circuit.

NO Voltage: There is not a complete circuit. The circuit's normal ground (GND) paths have been disconnected, and there is no other connection between the isolated circuit and ground (GND) - no short has been detected.


CAUTION

Direct contact with meter probes at the connector terminals can easily damage the small contacts, causing poor connections and risking future intermittent malfunctions.

Special Tools include adapters for making test connections safely and preventing connector damage. See 2. Test Equipment.



Fuse/Relay Panel (Left Side Plenum Tray)




97-7025

Fuse arrangement

	Amp.	Current track		Amp.	Current track		
1	Fog Lights/Rear Fog Lights	15A	216	6	Parking Lights, Side Marker and Tail Lights, Right	5A	195
2	Emergency Flashers	15A	262	7	Parking Lights, Side Marker and Tail Lights, Left	5A	193
3	Dual Horns/Heated Seats	30A	281	8	High Beam Headlight, Right/Headlight High Beam Indicator Light	10A	187
4	Digital Clock/Luggage Compartment Light/Interior Light, Front/Make-Up Mirror Lights/Reading Lights/Cigarette Lighters/Board-computer/Automatic Climate Control/Radio/Auto Check System	15A	419	9	High Beam Headlight, Left	10A	188
5	Coolant Fan	30A	253	10	Lowbeam Headlight, Right	10A	189
				11	Lowbeam Headlight, Left	10A	190

Fuse/Relay Panel (Left Side Plenum Tray)



Fuse Colors


- 30A - Green
- 25A - Clear (White)
- 20A - Yellow
- 15A - Blue
- 10A - Red
- 5A - Light Brown

97-7025

Fuse arrangement

	Amp.	Current track		Amp.	Current track		
12	Cruise Control/ElectronicThermostat/Auto Check System/Instrument Cluster/Interior Light With Delay/Back-Up Lights/Servotronic/Automatic Transmission/Airbag Control Light/Coolant Fan Afterrun/Differential Lock/Board Computer	15A	297	18	Power Mirrors	5A	499
13	Injectors/FP (Fuel Pump)	15A	96	19	Central Locking/Alarm System Heated Door Locks	10A	366
14	License Plate Light/Glove Compartment Light/Engine Compartment Light	5A	225	20	First Speed Coolant Fan/Coolant Fan Afterrun	30A	239
15	Windshield Wiper And Washer/Washer Nozzle Heaters/Turn Signal Lights/Coolant Fan/Air Conditioning	25A	258	21	On-Board Diagnostics (OBD)	10A	82
16	Rear Window Defogger/Heated Mirrors	30A	289	22	Open		97
17	Automatic Climate Control/Fresh Air Blower	30A	304				

Fuse/Relay Panel (Left Side Plenum Tray)



97-7025


Auxiliary fuse arrangement

Auxiliary fuse holder colors

	Amp.	Current track		
23 License Plate Light With Daytime Running Lights (Canada Only)	5A		S23	- Black
24 Not Used	20A		S24	- Blue
25 Heated Oxygen Sensor (HO2S)	5A		S25	- Red
26 Trailer Connector	30A		S26	- Yellow
27 Engine Control I	10A	15	S27	- Brown
28 Engine Control II (Injectors)	15A	51	S28	- White
29 Brake Lights	10A	307	S29	- Green
30 Cruise Control (Automatic Transmission)	5A		S30	- Gray
31 ABS/Differential Lock	15A	349	S31	- Orange
32 Engine Control III (Ignition Coil Power Output Stages)	20A	17	S32	- Violet

Note: Auxiliary Fuses 27 and 28 are covered with a red cap marked with the words "Motor Moteur" to prevent accidental fuse removal.

Fuse/Relay Panel (Left Side Plenum Tray)



97-7025

On-Board Diagnostic (OBD)


- A - Wire Distributor For DLC (Data Link Connector); Terminal K
- B - Wire Distributor For DLC (Data Link Connector); Terminal L

Note: All vehicle systems equipped with On-Board Diagnostics (OBD) are connected to the Data Link Connectors via wire distributors K and L.

Data Link Connector (DLC)

- C - Black
 - Terminal 1 - Ground (GND)
 - Terminal 2 - Battery Positive Voltage (B+, Terminal 30, Via Fuse)
- D - White - Data Transfer (For All Systems With OBD)
- E - Blue - Blink Code Output (Not For All Systems With OBD)

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- 1 Fog Light Relay, J5
- 2 Second Speed Coolant FC (Fan Control) Relay, J101
- 3 After-Run Coolant FC (Fan Control) Control Module, J138
- 4 Headlight Washer System Relay, J39
- 5 Load Reduction Relay, J59
- 6 Heater Fan Relay, J11 (Manual Air-Conditioning Only)
Second Speed Coolant FC (Fan Control) Relay, J101 (Automatic Climate Control)
- 7 Dual Horn Relay, J4
- 8 Alarm System Relay (Starter Interlock), J60 (Manual Transmission Only)
Bridge Connection (Manual Transmission Without Alarm System)
Open (Automatic Transmission)
- 9 Washer /Wiper Intermittent Relay, J31
- 10 FP (Fuel Pump) Relay, J17
- 11 Coolant FC (Fan Control) Relay, J26

Auxiliary Relay Panel With Connector Station



A – Not Used B – Fuse Adapter For Coolant Fan C – Fuse Adaptor For Circuit Breakers

97-7024

Relay location


- | | |
|--|--|
| <ul style="list-style-type: none"> 1 Shift Lock Control Module, J221 (Automatic Transmission Only) 2 PNP (Park/Neutral Position) Relay, J226 3 4
A/C Compressor Clutch Control Module, J153 (Manual Air-Conditioning Only) 4 A/C Compressor Clutch Relay, J44 (Automatic Climate Control Only) 5 Power Window And Sunroof Control Module, J139 6 Power Window And Sunroof Control Module, J139 7 Fuel Gauge Damper Control Module, J273 (Quattro Only) 8 Automatic Transmission Console Light Switch-Over Relay, J307 (USA And Canada Only) 9 Overload Protection For Airbag 10 Daytime Running Lights Relay (Switch-On), J90 11 Program Switch Light Relay (Automatic Transmission Only), J300 12 Seat Belt Warning Control Module, J34 (Auto Check System/USA Only) 13 Open 14 Open | <ul style="list-style-type: none"> 15 Lamp Control Module, Front, J123 (With Auto Check System Only) 16 Open 17 Open 18 Third Speed Coolant FC (Fan Control) Relay, J135 (Manual Air-Conditioning Only)
Second Speed Coolant FC (Fan Control) Relay, J101 (Automatic Climate Control Only) |
|--|--|

Fuse Arrangement For Fuse Adapters A - B - C

- Fuse For Coolant Fan In Adapter B, S42 (60A)
- Power Window Circuit Breaker In Adapter C, S43 (20A)
- Memory Seat Adjusting Circuit Breaker In Adapter C, S44 (30A)
- Power Seat Circuit Breaker In Adapter C, S80 (20A)
- Sunroof Circuit Breaker In Adapter C, S83 (20A)

Note: Fuses in Fuse Adapter C are installed in any free position and are not allocated any specific position

Auxiliary Relay Panel, Rear (Below Rear Seat, Left)




97-7026

Relay location

- 19 Open
- 20 Open
- 21 Open
- 22 ABS Combi Relay, J156
Overload Protection For Airbag

Connector Identification On Connector Station




97-4191

- | | |
|---|---|
| 1 - Windshield Wiper Motor Wiring Harness (Black) | 4a - Cruise Control Wiring Harness (Blue) |
| 2 - Automatic Transmission Wiring Harness (Green) | 5 - Rear Wiring Harness (Brown) |
| 2a - AC Wiring Harness (Green) | 5a - Door Contact Switch Wiring Harness (Brown) |
| 3 - Left Front Wiring Harness (Yellow) | 6 - Right Front Wiring Harness (Black) |
| 3a - Heated Seats Wiring Harness (Yellow) | 6a - Right Front Wiring Harness (Black) |
| 4 - ABS Wiring Harness (Blue) | |

Note: If there is no harness for a particular option, an empty connector housing will occupy its place.

Connections And Plugs On Fuse/Relay Panel, Rear (Back Side)



97-5083

- A - Airconditioning wiring harness (gray), eight point
- B - Right front wiring harness (black), eight point
- C - Instrument panel wiring harness (blue), eight point
- D - Left front wiring harness (green), eight point
- E - Left front wiring harness (yellow), eight point
- F - Instrument panel wiring harness (brown), eight point
- G - Instrument panel wiring harness (red), eight point
- H - Rear wiring harness (black), six point
- I - Instrument panel wiring harness (red), six point
- J - Instrument panel wiring harness (yellow), six point
- K - Connected to relay location 3 (black)
- L - Single connector, terminal 30 (B+)
- M - Single connectors for optional equipment
- N - Not used
- O - Not used
- P - Single connector, fuse 20

Description	Current track	Description	Current track
ABS Combi Relay, J156	339-344	Central Locking System Sensor, Left, G117	393-394
ABS Control Module, J104	309-336	Central Locking System Sensor, Right, G118	396-397
ABS Hydraulic Unit, N55	323-336	Central Locking/Alarm System/Interior Light Delay Control Module, V94	368-411
ABS Return Flow Pump Relay, J105	333-334	Cigarette Lighter Light, L28	426
ABS Return Flow Pump, V39	332	Cigarette Lighter Light, Rear, L32	431
ABS Solenoid Relay, J106	330-331	Cigarette Lighter, Rear, U9	415
ABS Solenoid Valve, LF, N59	328	Cigarette Lighter, U1	414
ABS Solenoid Valve, LR, N57	326	CKP (Crankshaft Position) Sensor, G4	72-74
ABS Solenoid Valve, RF, N58	327	Clock Light, L8	140
ABS Solenoid Valve, RR, N56	325	Cruise Control Switch, E45	351-355
ABS Speed Sensor, Left Front, G47	319-320	Cruise Control Vacuum Pump, V18	362-364
ABS Speed Sensor, Left Rear, G46	316-317	Cruise Control, Control Module, J213	357-364
ABS Speed Sensor, Right Front, G45	313-314	CTP (Closed Throttle Position) Switch, F60	34-35
ABS Speed Sensor, Right Rear, G44	310-311	Damping/Fuel Gauge Control Module, J273	93-94
ABS Switch Illumination, L56	349	Digital Clock, Y2	138-140
ABS Switch, E83	347	Dimmer/Rear Indicator Light, K60	130
ABS Warning Light, K47	162	DLC (Data Link Connector)	82
Airbag Control Light, K75	300	DLC (Data Link Connector), K	72
Airbag Energy Reserve, J177	507	DLC (Data Link Connector), L	74
Airbag Igniter, Driver Side, N95	513	Door Contact Switch, Left Front, F2	399-400
Airbag Spiral Spring, F138	513-514	Door Contact Switch, Left Rear, F10	401
Airbag Triggering Unit, J178	511-516	Door Contact Switch, Right Front, F3	403-404
Airbag Voltage Transformer, N96	506-508	Door Contact Switch, Right Rear, F11	406
Alarm Horn, H8	391	Door Lock Switch, E150	366-370
Alarm Switch, Driver Door Handle, F121	379-381	Dual Horn Relay, J4	284-286
Alarm Switch, Hood, F120	388	Dual Horns, H1	282-284
Alarm Switch, Passenger Door Handle, F122	382-384	ECL (Engine Coolant Level) Warning Switch, F66	99
Alarm Switch, Trunk Lid, F123	419	ECM (Engine Control Module), J192	16-92
Alarm Switch, Trunk Lock, F124	373-375	ECT (Engine Coolant Temperature) Gauge, G3	141
Alarm System Relay, J60	11-13	ECT (Engine Coolant Temperature) Sensor, G62	37
Ashtray Light, L15	428	ECT (Engine Coolant Temperature)/ECL (Engine Coolant Level) Warning Light, K28	124
Auto Check System, J189	103-131	EGR Frequency Valve, N18	63
Back-Up Light Switch, F4	302	EGR Temperature Sensor, G98	35
Back-Up Light, Left, M16	222	Electronic Thermoswitch, F76	101-102
Back-Up Light, Right, M17	224	Emergency Flasher Relay, J2	254-256
Battery, A	7	Emergency Flasher Switch, E3	258-265
Brake Fluid Level Warning Light, K33	125	Engine Oil Pressure Gauge Light, L27	545
Brake Fluid Level Warning Switch, F34	151	Engine Oil Pressure Gauge, G11	545
Brake Light Switch, F	307		
Brake Light, Left, M9	199		
Brake Light, Right, M10	204		
Brake Warning Light, K34	126		
Center Console Light Booster, J166	534-539		
Center Rear Ashtray Light, L50	429		

Description	Current track	Description	Current track
Engine Compartment Light, W27	232	GEN (Generator) Warning Light, K2	160
Engine Oil Pressure Sensor, G10	545	GEN (Generator), C	1-4
Engine Oil Pres. Switch (0.3 Bar), F22	104	Glove Compartment Light, W6	230
Engine Oil Pressure Switch, F1	106	Green Light Diode, Battery Voltage Above 12.5 Volts, K52	129
Engine Oil Pressure Warning Light, K3	122	Hall Generator, G40	87-88
Engine Oil Temperature Gauge Light, L24	542	Headlight Dimmer/Flasher Switch, E4	180-181
Engine Oil Temperature Gauge, G9	543	Headlight High Beam Indicator Light, K1	166
Engine Oil Temperature Sensor, G8	543	Headlight Washer Pump, V11	267
EVAP (Evaporative Emission) Frequency Valve, N80	68	Headlight Washer System Relay, J39	267-269
Fog Light Relay, J5	213-215	Headlight, Left, L1	190
Fog Light Switch Light, L40	217-218, 220-221	Headlight, Right, L2	189
Fog Light Switch, E7	215-216	High Beam Headlight, Left, L13	188
Fog Light, Left, L22	214	High Beam Headlight, Right, L14	187
Fog Light, Right, L23	216	High-Mount Brake Light, M25	208
FP (Fuel Pump) Relay, J17	49-53	HO2S (Heated Oxygen Sensor) II, G108	60
FP (Fuel Pump), G6	96	HO2S (Heated Oxygen Sensor), G39	57
Fuel Gauge Sending Unit, G	98	Horn Button, H	286
Fuel Gauge, G1	142	IAC (Idle Air Control Valve), N71	91
Fuel Reserve Indicator Light, K16	123	Ignition Coil 2, N128	22-24
Fuse, S1, 15A	216	Ignition Coil 3, N158	25-27
Fuse, S2, 15A	262	Ignition Coil, N	19-21
Fuse, S3, 25A	281	Ignition/Starter Switch, D	172-179
Fuse, S4, 15A	419	Injector, Cyl. 1, N30	46
Fuse, S5, 30A	253	Injector, Cyl. 2, N31	48
Fuse, S6, 5A	195	Injector, Cyl. 3, N32	50
Fuse, S7, 5A	193	Injector, Cyl. 4, N33	52
Fuse, S8, 10A	187	Injector, Cyl. 5, N83	54
Fuse, S9, 10A	188	Injector, Cyl. 6, N84	56
Fuse, S10, 10A	189	Instrument Panel Light Dimmer Switch, E20	149
Fuse, S11, 10A	190	Instrument Panel Light, L10	152-157
Fuse, S12, 15A	297	Interior Light, Front, W	435-437
Fuse, S13, 15A	96	KS (Knock Sensor) 1, G61	23-25
Fuse, S14, 5A	225	KS (Knock Sensor) 2, G66	26-28
Fuse, S15, 25A	258	Lamp Control Module, Front, J123	189-192
Fuse, S16, 30A	289	Lamp Control Module, Rear, J124	197-210
Fuse, S17, 30A	304	License Plate Light, X	226,228
Fuse, S18, 5A	499	Light Switch, E1	170-176
Fuse, S19, 10A	366	Load Reduction Relay, J59	170-171
Fuse, S20, 30A	239	Luggage Compartment Light, W3	419
Fuse, S21, 10A	82	Make-Up Mirror Light, Left, W20	445-446
Fuse, S22	97		
Fuse, S27, 10A	15		
Fuse, S28, 15A	51		
Fuse, S29, 10A	307		
Fuse, S31, 15A	349		
Fuse, S32, 20A	17		

Description	Current track
Make-Up Mirror Light, Right, W14	447-448
MAP (Manifold Absolute Pressure) Valve, N156	65
MIL (Malfunction Indicator Lamp), K83	163
MIRROR Adjustment Switch, E43	492-504
MAF (Mass Air Flow) Sensor, G70	15-18
Map/Reading Light, Right Front, W13	439-440
Mirror Heat Element, Left, Z4	492
Mirror Heat Element, Right, Z5	499
Mirror Motor, Left, V17	493-495
Mirror Motor, Right, V25	500-502
O2S (Oxygen Sensor) Heater, Z19	58
O2S (Oxygen Sensor) Heater, Z28	61
"OK" Symbol Indicator Light, K50	128
Parking Brake Indicator Light, K14	151
Parking Brake Warning Light Switch (Ground), F9	149
Parking Light, Left, M1	193
Parking Light, Right, M3	195
Power Output Stage, N122	29-32
Power Window Circuit Breaker, S43, 20A	451
Power Window Control Module, J139	450-469
PSP (Power Steering Pressure) Switch, F88	153
Radio, R (Prep.-Wiring)	421-425
Reading Light, Left Rear, W11	441-442
Reading Light, Right Rear, W12	443-444
Rear Fog Light Bulb/Connection, L20	221
Rear Fog Light Switch, E18	221-223
Rear Window Defogger Switch Light, L39	291-292
Rear Window Defogger Switch, E15	289-290
Rear Window Heat Element, Z1	289
RPM (Engine Speed) Sensor, G28	75-77
Seat Belt Switch, Left, E24	241
Seat Belt Warning Control Module, J34	240-250
Seat Belt Warning Light, K19	147
Servotronic Control Module, J236	522-527
Servotronic Solenoid Valve, N119	525-527
Side Marker Lights, Front, M11	198
Side Marker Lights, Rear, M12	207
Spark Plug Connectors, P	20,21,23, 24,26,27
Spark Plugs, Q	20,21,23, 24,26,27

Description	Current track
Speed Warning Indicator Light, K101	131
Speedometer, G21	167-168
Starter, B	10-12
Tachometer, G5	145-146
Tail Light, Left, M4	199
Tail Light, Right, M2	204
TP (Throttle Position) Sensor, G69	36-40
Turn Signal Indicator Light, Left, K65	159
Turn Signal Indicator Light, Right, K64	158
Turn Signal Light, Left Front, M5	194
Turn Signal Light, Left Rear, M6	201
Turn Signal Light, Right Front, M7	196
Turn Signal Light, Right Rear, M8	206
Turn Signal Switch, E2	268-270
Vacuum Vent Valve, Brake, F47	359
Vacuum Vent Valve, Clutch, F36	352
Voltage Stabilizer, J6	143-144
Voltmeter Light, L25	540
Voltmeter, G14	541
VR (Voltage Regulator), C1	1-4
VSS (Vehicle Speed Sensor), G22	167-168
Washer Nozzle Heater, Left, Z20	235
Washer Nozzle Heater, Right, Z21	237
Washer/Wiper Intermittent Relay, J31	273-275
Window Lockout Switch, E39	460
Window Motor, Left Front Door, V14	465
Window Motor, Left Rear Door, V26	473
Window Motor, Right Front Door, V15	486
Window Motor, Right Rear Door, V27	479
Window Switch, LR (in LF Door), E53	472-475
Window Switch, LR (in LR Door), E52	472-475
Window Switch, Left Front (in LF Door), E40	464-468
Window Switch RF (in RF Door), E107	485-488
Window Switch, Right Front (in LF Door), E41	485-488
Window Switch, RR (in LF Door), E55	478-481
Window Switch, RR (in RR Door), E54	478-481
Windshield Washer Fluid Level Indicator Light, K37	127
Windshield Washer Fluid Level Warning Switch, F77	271
Windshield Washer Pump, V5	273
Windshield Wiper Intermittent Switch, E22	271-276
Windshield Wiper Motor, V	275-279

Wire connectors

- T1a – single, in engine compartment, right
- T1b – single, black, near horn button
- T1d – single, brown, on Radio (Alarm System Contact)
- T1e – single, green, behind instrument panel, left
- T1f – single, black, behind instrument panel, left
- T1i – single, white, behind instrument panel, left
- T1k – single, blue, behind instrument panel
- T1l – single, red, behind instrument panel, left
- T1r – single, in engine compartment, right
- T1s – single, red, behind instrument panel, left
- T1v – single, black, below back seat, center
- T1y – single, in driver's door
- T1z – single, in passenger's door
- T2 – double, black, on High-Mount Brake Light
- T2a – double, below back seat, right
- T2aa – double, on Window Motor, Left Front Door
- T2ab – double, grey, near starter
- T2ap – double, in driver's door
- T2aq – double, in passenger's door
- T2b – double, in engine compartment, right
- T2c – double, below back seat, left
- T2d – double, in engine compartment, left
- T2e – double, near interior light
- T2f – double, near washer nozzle heater, left
- T2g – double, near washer nozzle heater, right
- T2i – double, white, for door contact switch, driver's door
- T2l – double, black, in engine compartment, left
- T2m – double, black, in engine compartment, right
- T2o – double, red, behind instrument panel
- T2p – double, yellow, behind instrument panel, left
- T2r – double, red, on Seat Belt Switch, Left
- T2s – double, brown, behind console
- T2v – double, white, behind instrument panel
- T2w – double, grey, in trunk lid
- T2x – double, black, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
- T2z – double, white, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
- T3 – three point, black, behind instrument panel, left
- T3b – three point, green, behind instrument panel, left
- T3f – three point, green, behind instrument panel, left
- T3i – three point, black, in trunk lid
- T3k – three point, white, on Ignition Coils, connector 15
- T3l – three point, black, on CKP (Crankshaft Position) Sensor
- T3m – three point, grey, on RPM (Engine Speed) Sensor
- T3n – three point, green, on KS (Knock Sensor)
- T3o – three point, blue, on KS (Knock Sensor) 1
- T3p – three point, white, on Power Output Stage
- T3u – three point, black, in luggage compartment, left
- T4g – four point, blue, on Power Output Stage
- T4h – four point, black, in engine compartment, left
- T4i – four point, green, behind instrument panel
- T5 – five point, black, connector station in auxiliary relay panel
- T5a – five point, brown, connector station in auxiliary relay panel
- T5c – five point, in Instrument Cluster
- T5d – five point, on heated mirror, right
- T5e – five point, on heated mirror, left
- T5f – five point, blue, behind instrument panel
- T5h – five point, red, behind instrument panel, left
- T6 – six point, connector station on auxiliary relay panel
- T6ae – six point, black, connector B on V94, below back seat, right
- T6b – six point, black, in luggage compartment, left rear
- T6c – six point, black, behind instrument panel, left
- T6g – six point, in Instrument Cluster
- T6h – six point, black, behind instrument panel
- T6k – six point, black, behind console
- T10 – ten point, black, connector station in auxiliary relay panel
- T10a – ten point, yellow, connector station in auxiliary relay panel
- T10b – ten point, brown, connector station in auxiliary relay panel
- T10d – ten point, blue, connector station in auxiliary relay panel
- T12 – twelve point, on ECM (Engine Control Module)
- T12a – twelve point, brown, on Cruise Control, Control Module
- T12b – twelve point, connector A on V94, below back seat, right
- T13 – thirteen point, brown, on Turn Signal Switch/Windshield Wiper Intermittent Switch
- T13a – thirteen point, black, on Light Switch/Headlight Dimmer/Flasher Switch
- T16 – sixteen point, connector C on V94, below back seat, right
- T16a – sixteen point, on ECM (Engine Control Module)
- T16b – sixteen point, on ECM (Engine Control Module)
- T20 – twenty point, on ECM (Engine Control Module)
- T26 – twenty-six point, yellow, on Instrument Cluster
- T26a – twenty-six point, blue, on Instrument Cluster
- T26b – twenty-six point, white, on Instrument Cluster (Auto Check System With Display)
- T35 – thirty-five point, on ABS Control Module

Welded wiring harness points

- A2 – plus connection (15), in instrument panel wiring harness
- A3 – plus connection (58), in instrument panel wiring harness
- A5 – plus connection (right turn signal), in instrument panel wiring harness
- A6 – plus connection (left turn signal), in instrument panel wiring harness
- A7 – plus connection (58 D1), in instrument panel wiring harness
- A9 – plus connection (56 b), in instrument panel wiring harness
- A17 – wire connection (61), in instrument panel wiring harness
- A18 – wire connection (54), in instrument panel wiring harness
- A19 – wire connection (58d), in instrument panel wiring harness
- A20 – wire connection (15a), in instrument panel wiring harness
- A21 – wire connection (86s), in instrument panel wiring harness
- A23 – wire connection (30a1), in instrument panel wiring harness
- A27 – wire connection (speed signal), in instrument panel wiring harness
- A32 – plus connection (30), in instrument panel wiring harness
- A33 – wire connection (75), in instrument panel wiring harness
- A41 – plus connection (50), in instrument panel wiring harness
- A42 – plus connection (fuel gauge), in instrument panel wiring harness
- A43 – wire connection (57l), in instrument panel wiring harness
- A44 – wire connection (57r), in instrument panel wiring harness
- A45 – wire connection (RPM signal), in instrument panel wiring harness
- A46 – plus connection (30–from radio), in instrument panel wiring harness
- D9 – plus connection (15, via fuse 24), in right front wiring harness
- D10 – plus connection (30), in right front wiring harness
- D11 – plus connection (15, via fuse 28), in right front wiring harness
- D14 – wire connection (ignition coil – control module), in right front wiring harness
- D95 – wire connection (injectors), in engine compartment wiring harness
- J1 – plus connection (30), in ABS wiring harness
- Q10 – plus connection (87), in power windows, power locks and door contact switch wiring harness
- Q11 – plus connection (30az), in power windows, power locks and door contact switch wiring harness
- Q14 – wire connection (lock–switch), in power windows/ power door lock and door contact switch wiring harness
- Q20 – wire connection –1– (door contact switch), in power window wiring harness
- Q22 – wire connection, in rear lid wiring harness
- Q42 – wire connection (door lock open), in power window wiring harness
- Q43 – wire connection (door lock locked), in power window wiring harness
- T1 – plus connection –1–, in airbag wiring harness
- T2 – plus connection –2–, in airbag wiring harness

Ground connections


- 6 – ground strap, engine to generator
- 11 – ground connection, in battery box
- 17 – ground connection, on intake manifold
- 22 – ground connection, on hydraulic unit
- 32 – ground connection, behind instrument panel, left
- 50 – ground connection, in luggage compartment, left
- 81 – ground connection -1-, in instrument panel wiring harness
- 83 – ground connection -1-, in right front wiring harness
- 84 – ground connection, engine block, in right front wiring harness
- 85 – ground connection -1-, in engine compartment wiring harness
- 89 – ground connection -1-, in power window wiring harness
- 98 – ground connection, in rear lid wiring harness
- 100 – ground connection -1-, in ABS wiring harness
- 105 – ground connection -1-, in central locking system wiring harness
- 107 – ground connection, in outside mirrors wiring harness
- 109 – ground connection, in airbag wiring harness
- 119 – ground connection -1-, in headlight wiring harness
- 124 – ground connection, in engine compartment right wiring harness
- 182 – ground connection -1-, in engine compartment wiring harness (6 Cylinder)

Wiring Color Code	
BK	BLACK
BR	BROWN
CL	CLEAR
R	RED
Y	YELLOW
G	GREEN
LT. G	LIGHT GREEN
BL	BLUE
V	VIOLET
GY	GRAY
W	WHITE
OR	ORANGE

Wire Size

Wiring Diagrams identify wires by the metric wire size. Metric wire sizes indicate cross-sectional area in square millimeters (mm²). The chart below lists metric wire sizes and their approximate equivalents in American Wire Gauge (AWG) sizes.


Metric Size Cross-Section (mm ²)	American Wire Gauge Size (AWG)
0.35	22
0.50	20
0.75	18
1.00	16
1.50	14
2.50	12
4.00	10
6.00	8
16.00	4
25.00	2
35.00	2



17 Generator (GEN)/Starter



90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

**This page
intentionally
left blank**




19 ECM (Engine Control Module)

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100



J192
ECM (Engine Control Module)


(K)





* California Only


90 (All models)-USA/Canada
Up to VIN: 8CPA 000100


ECM (Engine Control Module) **20**






90 (All models)-USA/Canada
Up to VIN: 8CPA 000100





90 (All models)-USA/Canada
Up to VIN: 8CPA 000100


30
15
X
31



25 Auto Check System

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

30
15
X
31





* For 90 S
See Auxiliary Diagram

113 114 115 116 117 118 119 120 121 122 123 124 125 126

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Auto Check system **26**





* For 90 S
See Auxiliary Diagram

127 128 129 130 131 132 133 134 135 136 137 138 139 140

27 Auto check system
Digital clock


90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

**This page
intentionally
left blank**



29 Instrument cluster


90 (All models)-USA/Canada
Up to VIN: 8CPA 000100



90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Instrument cluster **30**


* California Only




169 170 171 172 173 174 175 176 177 178 179 180 181 182


31 Ignition/starter switch

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




90 (All models)-USA/Canada
Up to VIN: 8CPA 000100







90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Fuse panel **34**




35 Engine/glove compartment light

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




37 Emergency flasher relay/ Emergency switch

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Windshield wiper intermittent switch **38**



39 Dual horns

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100



* Manual Transmission Only
90 CS Quattro (Automatic Transmission Only)


295 296 297 298 299 300 301 302 303 304 305 306 307 308

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Brake light switch
Back-up light switch **40**


30
15
X
31

* For Audi 90 CS Quattro and 90 CS Quattro Sport, see Auxillary Wiring Diagram "ABS Quattro"



41 ABS Control Module (2-Wheel drive system)

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

ABS Control Module
(2-Wheel drive system) **42**


30
15
X
31

* For Audi 90 CS Quattro and 90 CS Quattro Sport, see Auxiliary Wiring Diagram "ABS Quattro".




43 ABS Combi relay (2-Wheel drive system)

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




* Manual Transmission Only




* Automatic Transmission Only


45 Central locking system

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100



90 (All models)-USA/Canada
Up to VIN: 8CPA 000100






90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

Central locking system
Cigarette lighters **48**


30
15
X
31



49 Ashtray lights


90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

30
15
X
31




90 (All models)-USA/Canada
Up to VIN: 8CPA 000100


Interior lights
Reading lights **50**




51 Power window Control Module


90 (All models)-USA/Canada
Up to VIN: 8CPA 000100








90 (All models)-USA/Canada
Up to VIN: 8CPA 000100




55 Airbag triggering unit

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100



30
15
X
31



533 534 535 536 537 538 539 540 541 542 543 544 545 546

57 Engine oil temperature sensor
Engine oil pressure sensor

90 (All models)-USA/Canada
Up to VIN: 8CPA 000100

**This page
intentionally
left blank**

Description	Current track
Driver Backrest Adjusting Motor, V45	25-27
Driver Backrest Adjustment Switch, E96	25-27
Driver Seat Fore/Aft Adjusting Motor, V28	16-18
Driver Seat Fore/Aft Adjusting Switch, E61	16-23
Driver Seat Front Height Adjusting Motor, V29	2-4
Driver Seat Front Height Adjusting Switch, E62	2-4
Driver Seat Rear Height Adjusting Motor, V30	11-13
Driver Seat Rear Height Adjusting Switch, E63	11-13
Power Seat Circuit Breaker, S80, 30A	24
Seat Adjusting Circuit Breaker, S44, 30A	19

Switch positions - Seat	
Adjust to	Adjustment
X1	Seat forward
X2	Seat backward
Y1	Seat down
Y2	Seat up
Y3	Seat rear down
Y4	Seat rear up
Y5	Seat front down
Y6	Seat front up
X3	Backrest forward
X4	Backrest backward

Wire connectors


T60 – six point, brown, below driver's seat

Ground connections

32 – ground connection, behind instrument panel, left

95 – ground connection -1-, in seat adjuster wiring harness


30
15
X
31



61 8-Way power front driver's seat (w/o memory)

Up to VIN: 8CPA 000100

90 CS-USA/Canada
90 CS Quattro Sport-USA




90 CS-USA/Canada
90 CS Quattro Sport-USA

Up to VIN: 8CPA 000100

8-Way power front driver's seat
(w/o memory)

Auxiliary Relay Panel, Rear (Below Rear Seat, Left)



97-7026

Relay location

- 22** ABS Control Relay, J156
Overload Protection For Airbag

Description	Current track
ABS Acceleration Switch, F113	26-27
ABS Combi Relay, J156	31-36
ABS Control Module, J104	1-28
ABS Hydraulic Unit, N55	15-28
ABS Magnetic Valve, Rear, N77	18
ABS Return Flow Pump, V39	24
ABS Solenoid Relay, J106	22-23
ABS Solenoid Relay, J106	25-26
ABS Solenoid Valve, LF, N59	20
ABS Solenoid Valve, RF, N58	19
ABS Speed Sensor, Left Front, G47	11-12
ABS Speed Sensor, Left Rear, G46	8-9
ABS Speed Sensor, Right Front, G45	5-6
ABS Speed Sensor, Right Rear, G44	2-3
ABS Switch Illumination, L56	41
ABS Switch, E83	39
Brake Light Switch, F	8
Differential Lock Control Module, J187	51-54
Differential Lock Indicator Light, K81	49
Differential Lock Switch Illumination, L55	47-48
Differential Lock Switch Illumination, L61	52
Differential Lock Switch, Rear, F100	33
Fuse, S29, 10A	10
Fuse, S31, 15A	41
Rear Differential Lock Indicator Light, K46	44
Rear Differential Lock Switch, E121	51

Wire connectors

- T2a - double, below back seat, right
- T2ab - double, grey, near starter
- T2a1 - double, white, below back seat, left
- T2b - double, in engine compartment, right
- T2c - double, below back seat, left
- T2d - double, in engine compartment, left
- T8b - eight point, connector 3, on Radio
- T10a - ten point, yellow, connector station in auxiliary relay panel


- T10d - ten point, blue, connector station in auxiliary relay panel
- T12a - twelve point, brown, on Cruise Control, Control Module
- T26 - twenty-six point, yellow, on Instrument Cluster
- T26a - twenty-six point, blue, on Instrument Cluster
- T35 - thirty-five point, on ABS Control Module

Welded wiring harness points

- (A2) - plus connection (15), in instrument panel wiring harness
- (A17) - wire connection (61), in instrument panel wiring harness
- (A18) - wire connection (54), in instrument panel wiring harness
- (A19) - wire connection (58d), in instrument panel wiring harness
- (A27) - wire connection (speed signal), in instrument panel wiring harness
- (A32) - plus connection (30), in instrument panel wiring harness
- (J1) - plus connection (30), in ABS wiring harness

Ground connections


- (22) - ground connection, on hydraulic unit
- (32) - ground connection, behind instrument panel, left
- (81) - ground connection -1-, in instrument panel wiring harness
- (100) - ground connection -1-, in ABS wiring harness



65 ABS Quattro
(With rear differential lock)

Up to VIN: 8CPA 000100


90 CS Quattro Sport-USA
90 S Quattro-Canada



90 CS Quattro Sport-USA
90 S Quattro-Canada

Up to VIN: 8CPA 000100

ABS Quattro (With rear differential lock) **66**




67 ABS Quattro
(With rear differential lock)

Up to VIN: 8CPA 000100

90 CS Quattro Sport-USA
90 S Quattro-Canada

30
15
X
31



90 CS Quattro Sport-USA
90 S Quattro-Canada

Up to VIN: 8CPA 000100

ABS Quattro (With rear differential lock) **68**

Description

	Current track
Antenna Booster, R24 (AM, FM)	32-39
Antenna Booster, R24 (FM)	25-28
Antenna, R11 (AM, FM)	35
Antenna, R11 (FM)	27
Auto Check System, J189	19-21
Fuse, S4, 15A	1
Fuse, S16, 30A	39
Radio, R	3-36
Rear Window Defogger Switch	
Light, L39	41-42
Rear Window Defogger Switch, E15	39-40
Rear Window Heat Element, Z1	37
Speaker, Left Front, R2	16
Speaker, Right Front, R3	21
Tweeter, Left Rear, R14	4
Tweeter, Right Rear, R16	14
Woofers, Left Rear, R15	5-8
Woofers, Right Rear, R17	10-13

Wire connectors


- T1d - single, brown, on Radio (Alarm System Contact)
- T1e - single, green, behind instrument panel, left
- T1k - single, red, in luggage compartment, left
- T2af - double, on Tweeter, Right Rear
- T2ag - double, on Tweeter, Left Rear
- T5m - five point, on Woofers, Left Rear
- T5n - five point, on Woofers, Right Rear
- T6c - six point, black, behind instrument panel, left
- T6k - six point, black, behind console
- T8b - eight point, connector 3, on Radio
- T8c - eight point, connector 2, on Radio
- T10b - ten point, brown, connector station in auxiliary relay panel
- T10h - ten point, connector 1, on Radio
- T26 - twenty-six point, yellow, on Instrument Cluster
- T26b - twenty-six point, white, on Instrument Cluster (Auto Check System With Display)

Wired wiring harness points

- (A19) - wire connection (58d), in instrument panel wiring harness
- (A21) - wire connection (86s), in instrument panel wiring harness
- (A23) - wire connection (30a), in instrument panel wiring harness
- (A46) - plus connection (30-from radio), in instrument panel wiring harness
- (V1) - plus connection (30), in rear speaker wiring harness

Ground connections

- (81) - ground connection -1-, in instrument panel wiring harness




90S,90 CS—USA/Canada
90 CS Quattro Sport—USA

Up to VIN: 8CPA 000100

AM/FM stereo radio (Anti-theft)
with 6 speakers

70

30
15
X
31




71 AM/FM stereo radio (Anti-theft) with 6 speakers

Up to VIN: 8CPA 000100

90S,90 CS-USA/Canada
90 CS Quattro Sport-USA

15 16 17 18 19 20 21 22 23 24 25 26 27 28




90S,90 CS-USA/Canada
90 CS Quattro Sport-USA

Up to VIN: 8CPA 000100

AM/FM stereo radio (Anti-theft)
with 6 speakers

72

Fuse/Relay Panel (Left Side Plenum Tray)



97-7025


On-Board Diagnostic (OBD)

- A - Wire Distributor For DLC (Data Link Connector); Terminal K

Data Link Connector (DLC)

- C - Black
 - Terminal 1 - Ground (GND)
 - Terminal 2 - Battery Positive Voltage (B+, Terminal 30, Via Fuse)

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- II Coolant FC (Fan Control) Relay, J26

Auxiliary Relay Panel With Connector Station



A - Not Used B - Fuse Adapter For Coolant Fan C - Fuse Adapter For Circuit Breakers

97-7024

Relay location

- 4 A/C Compressor Clutch Relay, J44 (Automatic Climate Control Only)
- 18 Second Speed Coolant FC (Fan Control) Relay, J101 (Automatic Climate Control Only)

Fuse Arrangement For Fuse Adapter

- Fuse For Coolant Fan In Adapter B, S42 (60A)

Description	Current track
A/C Compressor Clutch Relay, J44	15-18
A/C Compressor Clutch, N25	28
A/C Compressor Speed Sensor, G111	53-54
A/C Control Head, E87	1-70
A/C Refrigerant High Pressure Switch, F23	83
A/C Refrigerant High Pressure Switch, F118	50
A/C Refrigerant Low Pressure Switch, F73	14
Central Flap Motor Potentiometer, G112	69-70
Central Flap Motor, V70	67-68
Coolant Fan, V7	71-72, 73-74, 75-77
Coolant FC (Fan Control) Relay, J26	73-75
Coolant FC (Fan Control) Series Resistance, N39	77
Coolant FC (Fan Control) Thermo-switch, F18	81
Coolant FC (Fan Control) Thermo-switch, F54	24
DLC (Data Link Connector)	44
DLC (Data Link Connector), K	40-41
ECM (Engine Control Module), J192	21
Fan For Interior Temperature Sensor, V42	63-64
Footwell/Defrost Flap Motor Potentiometer, G114	61-62
Footwell/Defroster Flap Motor, V85	1-2
Fresh Air Blower Control Module, J126	4
Fresh Air Blower, V2	30
Fresh Air Intake Duct Temperature Sensor, G89	8
Fresh Air/Recirculating Flap Two-Way Valve, N63	38
Fuse, S4, 15A	57
Fuse, S12, 15A	32
Fuse, S14, 5A	72
Fuse, S15, 25A	20
Fuse, S17, 30A	24
Fuse, S21, 10A	84
Fuse, S42, 60A	33
Interior Temperature Sensor, Headliner, G86	44
Interior Temperature Sensor, Instrument Panel, G56	47
Outside Air (Ambient) Temperature Sensor, G17	62-64
Outside Air Temperature Display, G106	

Description	Current track
Protection Diode, J201	27
Second Speed Coolant FC (Fan Control) Relay, J101	79-81
Temperature Regulator Flap Motor Potentiometer, G92	59-60
Temperature Regulator Flap Motor, V68	57-58

Wire connectors

T1m	- single, red, behind instrument panel, left
T1n	- single, green, near compressor
T2am	- double, green, near compressor
T2t	- double, brown, behind instrument panel, left
T2u	- double, red, behind instrument panel, center
T2x	- double, black, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
T2z	- double, black, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
T3c	- three point, brown, behind instrument panel, center
T3f	- three point, green, behind instrument panel, left
T5g	- five point, green, connector station in auxiliary relay panel
T5h	- five point, red, behind instrument panel, left
T5l	- five point, yellow, on Outside Air Temperature Display
T5o	- five point, red, behind instrument panel, center
T6q	- six point, red, behind instrument panel, left
T10e	- ten point, red, behind instrument panel, center
A	- twelve point, on A/C Control Head
T13a	- thirteen point, black, on Light Switch/Headlight Dimmer/Flasher Switch
T16a	- sixteen point, on ECM (Engine Control Module)
C	- sixteen point, on A/C Control Head
D	- sixteen point, on A/C Control Head
B	- twenty point, on A/C Control Head
T26	- twenty-six point, yellow, on Instrument Cluster
T38	- thirty-eight point, on TCM (Transmission Control Module)

Welded wiring harness points


- Ⓐ3 – plus connection (58), in instrument panel wiring harness
- Ⓐ19 – wire connection (58d), in instrument panel wiring harness
- Ⓐ20 – wire connection (15a), in instrument panel wiring harness
- Ⓐ23 – wire connection (30a), in instrument panel wiring harness
- Ⓐ27 – wire connection (speed signal), in instrument panel wiring harness
- Ⓐ34 – wire connection (75x), in instrument panel wiring harness
- Ⓐ45 – wire connection (RPM signal), in instrument panel wiring harness
- Ⓕ1 – plus connection (75), in A/C wiring harness
- Ⓕ2 – wire connection, in A/C wiring harness
- Ⓕ4 – wire connection (75 a), in A/C wiring harness
- Ⓕ5 – wire connection -1-, in evaporator housing wiring harness
- Ⓕ9 – wire connection -1-, in A/C wiring harness
- Ⓕ31 – wire connection (5 Volts), in A/C wiring harness


Ground connections

- 11 – ground connection, in battery box
- 29 – ground connection, near compressor
- 32 – ground connection, behind instrument panel, left
- 81 – ground connection -1-, in instrument panel wiring harness


Ground connections


- 83 – ground connection -1-, in right front wiring harness
- 97 – ground connection -1-, in A/C wiring harness
- 112 – ground connection -2-, in A/C wiring harness
- 127 – ground connection -1-, in A/C compressor wiring harness
- 187 – ground connection -2-, in A/C compressor wiring harness
- 188 – ground connection -3-, in A/C wiring harness







**E87
A/C Control Head**






DLC (Data Link Connector)






* 90 CS Quattro Sport.
90 S And 90 CS From July 1992



90 CS-USA/Canada
90 CS Quattro Sport-USA

Fuse/Relay Panel (Left Side Plenum Tray)




97-7025

On-Board Diagnostic (OBD)

A - Wire Distributor For DLC (Data Link Connector); Terminal K

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- 8 Open (Automatic Transmission)

Auxiliary Relay Panel With Connector Station



A - Not Used

B - Fuse Adapter For Coolant Fan

C - Fuse Adapter For Circuit Breakers

97-7024

Relay location

- 1** Shift Lock Control Module, J221 (Automatic Transmission Only)
- 2** PNP (Park/Neutral Position) Relay, J226
- 8** Automatic Transmission Console Light Switch-Over Relay, J307 (USA And Canada Only)
- 11** Program Switch Light Relay, J300 (Automatic Transmission Only)

Description	Current track
Automatic Transmission Console Light Switch-Over Relay, J307	65-68
Automatic Transmission Console Light, L19	65
Back-Up Light, Left, M16	40
Back-Up Light, Right, M17	42
Central Locking/Alarm System/Interior Light Delay Control Module, V96	36
Cruise Control Switch, E45	71-75
Cruise Control Vacuum Pump, V18	82-84
Cruise Control, Control Module, J213	77-84
DLC (Data Link Connector), K	2
ECM (Engine Control Module), J192	8-14
Fuse, S4, 15A	65
Fuse, S12, 15A	59
Fuse, S14, 5A	61
Fuse, S30, 5A	15
Gear Selection Indicator, G96	61-62
Kick-Down Switch, F8	16
Multi-Function Switch (Digimat), F125	43-56
PNP (Park/Neutral Position) Relay, J226	49-56
Program Switch Illumination, L70	31-32
Program Switch Light Relay, J300	57-59
Protection Diode, J201	68
Shift Lock Control Module, J221	19-24
Shift Lock Solenoid, N110	20
Solenoid Valve 1, N88	7
Solenoid Valve 2, N89	8
Solenoid Valve 3, N90	9
Solenoid Valve 4, N91	10
Solenoid Valve 5, N92	11
Solenoid Valve 6, N93	12
Solenoid Valve 7, N94	13
TCM (Transmission Control Module), J217	1-47
TR (Transmission Range) Program Switch (Auto. Trans.), E122	30-33
Transmission Fluid Temperature Sensor, G93	14
Vacuum Vent Valve, Brake, F47	79
VSS (Vehicle Speed Sensor), G38	1-2

Wire connectors

- T1f - single, black, behind instrument panel, left
- T1m - single, red, behind instrument panel, left
- T1s - single, red, behind instrument panel, left

- T1v - single, black, below back seat, center
- T2ab - double, grey, near starter
- T2v - double, white, behind instrument panel
- T2z - double, white, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
- T4e - four point, black, behind instrument panel
- T4d - four point, black, behind instrument panel
- T5 - five point, black, connector station in auxiliary relay panel
- T5f - five point, blue, behind instrument panel
- T5i - five point, black, behind instrument panel
- T5o - five point, red, behind instrument panel, center
- T6b - six point, black, in luggage compartment, left rear
- T6h - six point, black, behind instrument panel
- T10a - ten point, yellow, connector station in auxiliary relay panel
- T10c - ten point, green, connector station in auxiliary relay panel
- T10d - ten point, blue, connector station in auxiliary relay panel
- T12a - twelve point, brown, on Cruise Control, Control Module
- T16 - sixteen point, connector C on V94, below back seat, right
- T16d - sixteen point, on A/C Control Head
- T20 - twenty point, on ECM (Engine Control Module)
- T26 - twenty-six point, yellow, on Instrument Cluster
- T38 - thirty-eight point, on TCM (Transmission Control Module)

Welded wiring harness points

- (A3) - plus connection (58), in instrument panel wiring harness
- (A7) - plus connection (58 D1), in instrument panel wiring harness
- (A17) - wire connection (61), in instrument panel wiring harness
- (A18) - wire connection (54), in instrument panel wiring harness
- (A19) - wire connection (58d), in instrument panel wiring harness
- (A20) - wire connection (15a), in instrument panel wiring harness
- (A23) - wire connection (30a1), in instrument panel wiring harness


- Ⓐ27 – wire connection (speed signal), in instrument panel wiring harness
- Ⓐ41 – plus connection (50), in instrument panel wiring harness
- Ⓐ45 – wire connection (RPM signal), in instrument panel wiring harness
- ⓤ2 – wire connection -1- (15), in automatic transmission wiring harness

Ground connections


- 17 – ground connection, on intake manifold
- 32 – ground connection, behind instrument panel, left
- 81 – ground connection -1-, in instrument panel wiring harness
- 83 – ground connection -1-, in right front wiring harness
- 98 – ground connection, in rear lid wiring harness
- 105 – ground connection -1-, in central locking system wiring harness
- 114 – ground connection, in automatic transmission wiring harness
- 150 – ground connection, in Automatic Transmission (Digimat/AG4) wiring harness

30
15
X
31


DLC (Data Link Connector)



J192 ECM (Engine Control Module)




J217 TCM (Transmission Control Module)





G38 VSS (Vehicle Speed Sensor)

* In Plenum Tray, Near Relay Panel


1 2 3 4 5 6 7 8 9 10 11 12 13 14







90 S, 90 CS—USA/Canada
Up to VIN: 8CPA 000100

30
15
X
31






30
15
X
31



95 Automatic Transmission and Cruise control (2-Wheel drive)

90 S, 90 CS—USA/Canada
Up to VIN: 8CPA 000100

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- 1 Fog Light Relay, J5
- 5 Load Reduction Relay, J59
- 7 Dual Horn Relay, J4

Auxiliary Relay Panel With Connector Station



A – Not Used B – Fuse Adapter For Coolant Fan C – Fuse Adapter For Circuit Breakers

97-7024

Relay location

- 7** Fuel Gauge Damper Control Module, J273 (Quattro Only)
- 10** Daytime Running Lights Relay (Switch-On), J90 (Canada Only)
- 15** Lamp Control Module, Front, J123 (Auto Check System Only)

Description**Current track**

Back-Up Light, Left, M16	54
Back-Up Light, Right, M17	56
Brake Light, Left, M9	31
Brake Light, Right, M10	36
Daytime Running Lights Relay (Switch-On), J90	44-45
Fog Light Relay, J5	45-47
Fog Light Switch Light, L40	48-50, 52-53
Fog Light Switch, E7	47-48
Fog Light, Left, L22	46
Fog Light, Right, L23	48
Fuse, S1, 15A	48
Fuse, S6, 5A	27
Fuse, S7, 5A	25
Fuse, S8, 10A	19
Fuse, S9, 10A	20
Fuse, S10, 10A	21
Fuse, S11, 10A	22
Fuse, S12, 15A	33
Fuse, S23, 5A	7
Fuse, S29, 10A	14
Headlight Dimmer/Flasher Switch, E4	12-13
Headlight, Left, L1	22
Headlight, Right, L2	21
High Beam Headlight, Left, L13	20
High Beam Headlight, Right, L14	19
High-mount Brake Light, M25	40
Ignition/Starter Switch, D	5-11
Lamp Control Module, Front, J123	21-24
Lamp Control Module, Rear, J124	29-42
License Plate Light, X	43,44
Light Switch, E1	2-8
Load Reduction Relay, J59	2-3
Parking Light, Left, M1	25
Parking Light, Right, M3	27
Rear Fog Light Bulb/Connection, L20	53
Rear Fog Light Switch, E18	53-55
Series Resistance Wire, N74	10
Side Marker Lights, Front, M11	30, 39
Tail Light, Left, M4	31
Tail Light, Right, M2	36
Turn Signal Light, Left Front, M5	26
Turn Signal Light, Left Rear, M6	33
Turn Signal Light, Right Front, M7	28
Turn Signal Light, Right Rear, M8	38

Wire connectors

- T1f - single, behind instrument panel, left
- T2 - double, black, on High-Mount Brake Light
- T2l - double, black, in engine compartment, left
- T2m - double, black, in engine compartment, right
- T2n - double, brown, behind instrument panel, left
- T6b - six point, black, in luggage compartment, left rear
- T10a - ten point, yellow, connector station in auxiliary relay panel
- T10b - ten point, brown, connector station in auxiliary relay panel
- T13a - thirteen point, black, on Light Switch/Headlight Dimmer/Flasher Switch
- T26a - twenty-six point, blue, on Instrument Cluster
- T26b - twenty-six point, white, on Instrument Cluster (Auto Check System With Display)


Welded wiring harness points

- A2 - plus connection (15), in instrument panel wiring harness
- A3 - plus connection (58), in instrument panel wiring harness
- A5 - plus connection (right turn signal), in instrument panel wiring harness
- A6 - plus connection (left turn signal), in instrument panel wiring harness
- A9 - plus connection (56 b), in instrument panel wiring harness
- A17 - wire connection (61), in instrument panel wiring harness
- A18 - wire connection (54), in instrument panel wiring harness
- A19 - wire connection (58d), in instrument panel wiring harness
- A20 - wire connection (15a), in instrument panel wiring harness
- A21 - wire connection (86s), in instrument panel wiring harness


- Ⓐ32 – plus connection (30), in instrument panel wiring harness
- Ⓐ33 – wire connection (75), in instrument panel wiring harness
- Ⓐ41 – plus connection (50), in instrument panel wiring harness
- Ⓐ43 – wire connection (57l), in instrument panel wiring harness
- Ⓐ44 – wire connection (57r), in instrument panel wiring harness

Ground connections

- 32 – ground connection, behind instrument panel, left
- 50 – ground connection, in luggage compartment, left
- 81 – ground connection -1-, in instrument panel wiring harness
- 98 – ground connection, in rear lid wiring harness
- 119 – ground connection -1-, in headlight wiring harness




* Quattro Only



90 S, 90 S Quattro, 90 CS
Canada only


Up to VIN: 8CPA 000100



103 Daytime running lights

Up to VIN: 8CPA 000100

90 S, 90 S Quattro, 90 CS
Canada only



90 S, 90 S Quattro, 90 CS
Canada only

Up to VIN: 8CPA 000100

Daytime running lights

Description**Current
track**

Door Lock Heater, Left, Z22
Door Lock Heater, Right, Z23
Fuse, S19, 10A
Heated Door Lock Control Module,
Left, J210
Heated Door Lock Control Module,
Right, J211
Heated Door Control Switch, Left,
E125
Heated Door Lock Switch, Right,
E126


5
11
2
2-6
8-12
3
9

Wire connectors

T1aw - single, brown, in heated door locks harness

Ground connections

32 - ground connection, behind instrument panel,
left



Description	Current track
Driver Seat Heater Temperature Sensor, G59	4
Fuse, S3, 30A	5
Fuse, S12, 15A	2
Heat Element, Driver Backrest, Z7	5
Heat Element, Driver Seat, Z6	5
Heat Element, Passenger Backrest, Z9,	13
Heat Element, Passenger Seat, Z8	13
Heat Regulating Switch, Driver Seat, E94	2-5
Heat Regulating Switch, Passenger Seat, E95	10-13
Passenger Seat Heater Control Switch, G60	12

Wire connectors


- T5k – five point, yellow, connector station in auxiliary relay panel
- T6l – six point, under passenger's seat
- T6m – six point, under driver's seat

Welded wiring harness points

- (A20) – wire connection (15a), in instrument panel wiring harness
- (O5) – wire connection -1- (15a), in heated seats wiring harness

Ground connections

- (32) – ground connection, behind instrument panel, left
- (81) – ground connection -1-, in instrument panel wiring harness
- (96) – ground connection -1-, in heated seats wiring harness




90 S, 90 CS-USA/Canada
90 S Quattro Sport-USA

Up to VIN: 8CPA 000100

Heated front seats **108**


Fuse/Relay Panel (Left Side Plenum Tray)



On Board Diagnostic (OBD)

A – Wire Distributor For DLC (Data Link Connector); Terminal K

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- 6** Heater Fan Relay, J11 (Manual Air Conditioning Only)
- 11** Coolant FC (Fan Control) Relay, J26

Auxiliary Relay Panel With Connector Station



A – Not Used B – Fuse Adapter For Coolant Fan C – Fuse Adapter For Circuit Breakers

97-7024

Relay location

- 3** **4** A/C Compressor Clutch Control Module, J153 (Manual Air Conditioning Only)
- 18** Third Speed Coolant FC (Fan Control) Relay, J135 (Manual Air Conditioning Only)

Fuse Arrangement For Fuse Adapter

- Fuse For Coolant Fan In Adapter B, S42 (60A)

Description	Current track
A/C Compressor Clutch Control Module, J153	9-22
A/C Compressor Clutch, N25	19
A/C Compressor Speed Sensor, G111	15-16
A/C Diode, J28	46
A/C Refrigerant High Pressure Switch, F23	55
A/C Refrigerant High Pressure Switch, F118	21
A/C Refrigerant Low Pressure Switch, F73	13
A/C Switch, E30	31-39
Ambient Temperature Switch, F38	38
Coolant Fan, V7	44,45
Coolant FC (Fan Control) Relay, J26	45-48
Coolant FC (Fan Control) Series Resistance, N39	44-45
Coolant FC (Fan Control) Thermo-switch, F18	48
Coolant FC (Fan Control) Thermo-switch, F54	51
DLC (Data Link Connector), K	16
ECM (Engine Control Module), J192	26-28
Fresh Air Blower Deries Resistance With Fuse, N24	3-8
Fresh Air Blower Switch, E9	1-7
Fresh Air Blower, V2	10
Fresh Air Control Lever Light, L16	1-2
Fresh Air/Recirculating Flap Two-Way Valve, N63	29
Fuse, S15, 25A	56
Fuse, S17, 30A	41
Fuse, S42, 60A	50
Heater Fan Relay, J11	25-27
Protection Diode, J201	18
Third Speed Coolant FC (Fan Control) Relay, J135	51-53

Wire connectors

- T1m - single, red, behind instrument panel, left
- T1n - single, green, near compressor
- T2am - double, green, near compressor
- T2q - double, behind instrument panel, center
- T2z - double, white, in left plenum, on fuse/relay panel, DLC (Data Link Connector)
- T3c - three point, brown, behind instrument panel, center
- T3f - three point, green, behind instrument panel, left


- T5g - five point, green, connector station in auxiliary relay panel
- T5h - five point, red, behind instrument panel, left
- T8a - eight point, red, behind instrument panel, center
- T10 - ten point, black, connector station in auxiliary relay panel
- T16a - sixteen point, on ECM (Engine Control Module)
- T20 - twenty point, on ECM (Engine Control Module)
- T26 - twenty-six point, yellow, on Instrument Cluster
- T38 - thirty-eight point, on TCM (Transmission Control Module)


Welded wiring harness points


- (A19) - wire connection (58d), in instrument panel wiring harness
- (A34) - wire connection (75x), in instrument panel wiring harness
- (A45) - wire connection (RPM signal), in instrument panel wiring harness
- (L1) - plus connection (75), in A/C wiring harness
- (L13) - plus connection (75 al), in fresh air blower wiring harness


Ground connections

- (11) - ground connection, in battery box
- (29) - ground connection, near compressor
- (32) - ground connection, behind instrument panel, left
- (81) - ground connection -1-, in instrument panel wiring harness
- (127) - ground connection -1-, in A/C compressor wiring harness










* Manual Transmission Only

90 S—USA/Canada
90 S Quattro—Canada

Up to VIN: 8CPA 000100

Fuse/Relay Panel (Left Side Plenum Tray)




97-7023

Relay location

- 4 Headlight Washer System Relay, J39

Auxiliary Relay Panel With Connector Station



A - Not Used

B - Fuse Adapter For Coolant Fan

C - Fuse Adapter For Circuit Breaker

97-7024

Relay location

- 12 Seat Belt Warning Control Module, J34 (USA Only)

Description	Current track
ABS Warning Light, K47	64
Brake Fluid Level Warning Light, K33	33
Brake Fluid Level Warning Switch, F34	53
Clock Light, L8	42
Digital Clock, Y2	40-42
ECL (Engine Coolant Level) Warning Switch, F66	1
ECM (Engine Control Module), J192	65-66
ECT (Engine Coolant Temperature) Gauge, G3	43
ECT (Engine Coolant Temperature)/ECL (Engine Coolant Level) Warning Light, K28	32
Electronic Thermoswitch, F76	3-4
Engine Oil Pressure Switch (0.3 Bar), F22	6
Engine Oil Pressure Switch, F1	8
Engine Oil Pressure Warning Light, K3	31
Fuel Gauge, G1	44
Fuse, S4, 15A	40
Fuse, S8, 10A	67
Fuse, S9, 10A	66
Fuse, S12, 15A	9
Fuse, S14, 5A	52
GEN (Generator) Warning Light, K2	62
Headlight High Beam Indicator Light, K1	68
Instrument Panel Light Dimmer Switch, E20	51
Instrument Panel Light, L10	54-59
MIL (Malfunction Indicator Lamp), K83	65
Mini Check System Control Module, J268	5-34
Parking Brake Indicator Light, K14	53
Parking Brake Warning Light Switch (Ground), F9	51
PSP (Power Steering Pressure) Switch, F88	55
Seat Belt Switch, Left, E24	24
Seat Belt Warning Control Module, J34	17-22
Seat Belt Warning Light, K19	49
Speedometer, G21	69-70
Tachometer, G5	47-48
Turn Signal Indicator Light, Left, K65	61
Turn Signal Indicator Light, Right, K64	60
Voltage Stabilizer, J6	45-46
VSS (Vehicle Speed Sensor), G22	69-70
Windshield Wiper Intermittent Switch, E22	58-61

Wire connectors

- T2r - double, red, on Seat Belt Switch, Left
- T3 - three point, behind instrument panel, left
- T4h - four point, black, in engine compartment, left
- T5 - five point, black, connector station in auxiliary relay panel
- T5c - five point, in Instrument Cluster
- T5h - five point, red, behind instrument panel, left
- T6g - six point, in Instrument Cluster
- T10 - ten point, black, connector station in auxiliary relay panel
- T10b - ten point, brown, connector station in auxiliary relay panel
- T10d - ten point, blue, connector station in auxiliary relay panel
- T12a - twelve point, brown, on Cruise Control, Control Module
- T13 - thirteen point, brown, on Turn Signal Switch/Windshield Wiper Intermittent Switch
- T13a - thirteen point, black, on Light Switch/Headlight Dimmer/Flasher Switch
- T14 - fourteen point, on Mini Check System Control Module
- T26 - twenty-six point, yellow, on Instrument Cluster
- T26a - twenty-six, blue, on Instrument Cluster
- T35 - thirty-five point, on ABS Control Module


Welded wiring harness points

- A2 - plus connection (15), in instrument panel wiring harness
- A3 - plus connection (58), in instrument panel wiring harness
- A5 - plus connection (right turn signal), in instrument panel wiring harness
- A6 - plus connection (left turn signal), in instrument panel wiring harness
- A7 - plus connection (58 D1), in instrument panel wiring harness
- A17 - wire connection (61), in instrument panel wiring harness
- A20 - wire connection (15a), in instrument panel wiring harness

- Ⓐ21 – wire connection (86s), in instrument panel wiring harness
- Ⓐ23 – wire connection (30a), in instrument panel wiring harness
- Ⓐ26 – wire connection (driver's door contact switch), in instrument panel wiring harness
- Ⓐ27 – wire connection (speed signal), in instrument panel wiring harness
- Ⓐ42 – plus connection (fuel gauge), in instrument panel wiring harness
- Ⓐ43 – wire connection (57l), in instrument panel wiring harness
- Ⓐ44 – wire connection (57r), in instrument panel wiring harness
- Ⓐ45 – wire connection (RPM signal), in instrument panel wiring harness
- Ⓐ46 – plus connection (30-from radio), in instrument panel wiring harness

Ground connections


- Ⓜ32 – ground connection, behind instrument panel, left
- Ⓜ81 – ground connection -1-, in instrument panel wiring harness
- Ⓜ83 – ground connection -1-, in right front wiring harness
- Ⓜ85 – ground connection -1-, in engine compartment wiring harness
- Ⓜ119 – ground connection -1-, in headlight wiring harness




90 S, 90 CS-USA/Canada
90 CS Quattro Sport-USA

Up to VIN: 8CPA 000100

Mini-check system **122**







29 30 31 32 33 34 35 36 37 38 39 40 41 42

90 S, 90 CS-USA/Canada
90 CS Quattro Sport-USA


Up to VIN: 8CPA 000100

Mini-check system **124**





Auxiliary Relay Panel With Connector Station



Relay location

- 5 Power Window And Sunroof Control Module, J139
- 6 Power Window And Sunroof Control Module, J139

Description

Current track

Power Window Control Module, J139
Sunroof Circuit Breaker, S83, 20A
Sunroof Motor, V1
Sunroof Relay, J72
Sunroof Stop Switch (Closed Pos.),
E56
Sunroof Stop Switch (Raise/Lower),
E60
Sunroof Switch, E8

1-5
3
8
11-14
6
5
7-9

Wire connectors


T1aa - single, green, in interior light and sunroof harness
T1x - single, green, behind instrument panel, left
T2i - double, white, for door contact switch, driver's door
T4k - four point, black, near sunroof switch
T5a - five point, brown, connector station in auxiliary relay panel

Welded wiring harness points

A26 - wire connection (driver's door contact switch), in instrument panel wiring harness
Q10 - plus connection (87), in power windows, power locks and door contact switch wiring harness

Ground connections

32 - ground connection, behind instrument panel, left
74 - ground connection, behind roof headliner




90 S, 90 CS-USA/Canada
90 CS Quattro Sport-USA

Up to VIN: 8CPA 000100

Tilt and slide power sunroof **130**


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

- 1** - Fog Light Relay, J5
- 4** - Headlight Washer System Relay, J39
- 5** - Load Reduction Relay, J59
- 7** - Dual Horn Relay, J4
- 8** { Alarm System Relay (Starter Interlock), J60 (Manual Transmission Only)
Bridge Connection (Manual Transmission Without Alarm System)
Open (Automatic Transmission)
- 9** - Washer / Wiper Intermittent Relay, J31
- 10** - Fuel Pump (FP) Relay, J17


Auxiliary Relay Panel With Connector Station



Relay location



- 7** - Fuel Gauge Damper Control Module (Quattro Only), J273
- 5** } Power Window And Sunroof Control Module, J139
- 6** }
- 9** - Airbag Control Light Relay, J312
- 12** - Seat Belt Warning Control Module, J34
- 15** - Lamp Control Module, Front, J123 (With Auto Check System Only)

Auxiliary Relay Panel, Rear (Left Side Plenum Tray)



Relay location


- 22** - ABS Combi Relay, J156
Overload Protection For Airbag



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow


97-15490

- (11) - Ground connection, in battery box
- (14) - Ground connection, on transmission
- (17) - Ground connection, on intake manifold
- (32) - Ground connection, behind instrument panel, left
- (81) - Ground connection -1-, in instrument panel wiring harness
- (83) - Ground connection -1-, in right front wiring harness
- (84) - Ground connection, engine block, in right front wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- (199) - Ground connection -3-, in instrument panel wiring harness



- A = Battery
 - B = Starter
 - C = Generator
 - C1 = Voltage Regulator
 - J60 = Alarm System Relay
 - T1h = Wire Connector, single, red, behind instrument panel, left
 - T2ab = Wire Connector, double, gray, near starter
- (6) - Ground strap, engine to generator
 - (11) - Ground connection, in battery box



30
15
X
31
a
b



97-15492

- J192 = MFI Engine Control Module (ECM)
- N = Ignition Coil 1
- N30 = Injector, Cyl. 1
- N31 = Injector, Cyl. 2
- N32 = Injector, Cyl. 3
- N33 = Injector, Cyl. 4
- N83 = Injector, Cyl. 5
- N84 = Injector, Cyl. 6
- N128 = Ignition Coil 2
- N158 = Ignition Coil 3
- P = Spark Plug Connector
- Q = Spark Plugs
- S32 = Fuse in auxiliary fuse holder (Ignition Coil, Engine Control III)
- T3k = Wire Connector, 3 Point, white, on Ignition Coils, connector 15

- (D14) - Wire connection (ignition coil - control module), in right front wiring harness
- (D95) - Wire connection (injectors), in engine compartment wiring harness




Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

97-15493


- F60 = Closed Throttle Position (CTP) Switch
- G40 = Hall Sensor
- G61 = Knock Sensor (KS) I
- G66 = Knock Sensor (KS) II
- G69 = Throttle Position (TP) Sensor
- G70 = Mass Air Flow (MAF) Sensor
- J192 = MFI Engine Control Module (ECM)
- N122 = Power Output Stage
- T3n = Wire Connector, 3 Point, green, on Knock Sensor (KS) II
- T3o = Wire Connector, 3 Point, blue, on Knock Sensor (KS) I
- T3p = Wire Connector, 3 Point, white, on Power Output Stage
- T4g = Wire Connector, 4 Point, brown, on Power Output Stage

- (17) - Ground connection, on intake manifold
- (124) - Ground connection, in engine compartment wiring harness right
- (182) - Ground connection -1-, in engine compartment wiring harness (6- Cylinder)



- G4 = Crankshaft Position (CKP) Sensor
- G28 = Engine Speed (RPM) Sensor
- G39 = Heated Oxygen Sensor (HO2S)
- G62 = EGR Temperature Sensor
- G98 = Engine Coolant Temperature (ECT) Sensor
- G108 = Heated Oxygen Sensor (HO2S) II
- J192 = MFI Engine Control Module (ECM)
- N71 = Idle Air Control (IAC) Valve
- S27 = Fuse in auxiliary fuse holder (Engine Control I)
- T1a = Wire Connector, single, in engine compartment, right
- T1r = Wire Connector, single, in engine compartment, right
- T3l = Wire Connector, 3 Point, black, on Crankshaft Position (CKP) Sensor
- T3m = Wire Connector, 3 Point, gray, on Engine Speed (RPM) Sensor
- T5 = Wire Connector, 5 Point, black, connector station in auxiliary relay panel
- T5h = Wire Connector, 5 Point, red, behind instrument panel, left
- Z19 = Oxygen Sensor (O2S) Heater
- Z28 = Oxygen Sensor (O2S) II Heater

- (83) - Ground connection -1-, in right front wiring harness
- (124) - Ground connection, in engine compartment right wiring harness
- (D9) - Plus connection (15, via fuse 27), in right front wiring harness
- (D10) - Plus connection (30), in right front wiring harness
- (D11) - Plus connection (15, via fuse 28), in right front wiring harness




97-15495

Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- G6 = Fuel Pump
- J17 = Fuel Pump (FP) Relay
- J192 = MFI Engine Control Module (ECM)
- N18 = EGR Vacuum Regulator Solenoid Valve
- N80 = Evaporative Emission (EVAP) Canister Purge Regulator Valve
- N156 = Intake Manifold Change-Over Valve
- S13 = Fuel pump Fuse, in Fuse Panel
- S21 = On-Bord Diagnostics (OBD) Fuse, in Fuse Panel
- S22 = Open
- S28 = Fuse in auxiliary fuse holder (Engine Control II -Injectors)
- T2x = Wire Connector, double, black, in Plenum, Near Relay Panel (Data Link Connector)
- T2z = Wire Connector, double, white, in Plenum, Near Relay Panel (Data Link Connector)
- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- (17) = Ground connection, on intake manifold
- (50) = Ground connection, in luggage compartment, left
- (83) = Ground connection -1-, in right front wiring harness
- (84) = Ground connection, engine block, in right front wiring harness
- (124) = Ground connection -1-, in engine compartment wiring harness, right
- (A27) = Wire connection (speed signal), in instrument panel wiring harness
- (D1) = Wire connection (15a), in right front wiring harness
- K = Wire Distributor For Data Link Connector (DLC); Terminal K
- L = Wire Distributor For Data Link Connector (DLC); Terminal L

90 (All models)—USA/Canada
From VIN: 8CPA 000100





97-15496

- D = Ignition / Starter Switch
- J59 = Load Reduction Relay
- J273 = Fuel Gauge Damper Control Module
- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- T10a = Wire Connector, 10 Point, yellow, connector station in auxiliary relay panel


- (199) - Ground connection -3-, in instrument panel wiring harness
- (A2) - Plus connection (15), in instrument panel wiring harness
- (A17) - Wire connection (61), in instrument panel wiring harness
- (A21) - Wire connection (86s), in instrument panel wiring harness
- (A33) - Wire connection (75), in instrument panel wiring harness
- (A41) - Wire connection (50), in instrument panel wiring harness
- * - Quattro only

139 Ignition/starter switch

90 (All models)-USA/Canada
From VIN: 8CPA 000100




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow



97-15497

- E20 = Instrument Panel Light Dimmer Switch
- G = Fuel Level Sensor
- G5 = Tachometer
- K15 = Starting Device Indicator Light
- K64 = Turn Signal Indicator Light, Right
- K65 = Turn Signal Indicator Light, Left
- K83 = Malfunction Indicator Lamp (MIL)
- L8 = Clock Light
- T6b = Wire Connector, 6 Point, black, in luggage compartment, left
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26a = Wire Connector, 26 Point, blue, on instrument cluster
- Y2 = Digital Clock

98 - Ground connection, in rear lid wiring harness





Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- G1 = Fuel Gauge
- G3 = Engine Coolant Temperature (ECT) Gauge
- G21 = Speedometer
- G22 = Vehicle Speed Sensor (VSS), Speedometer
- J6 = Voltage Stabilizer
- K47 = ABS Warning Light
- L10 = Instrument Cluster Light
- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26a = Wire Connector, 26 Point, blue, on instrument cluster

- (81) - Ground connection -1-, in instrument panel wiring harness
- (83) - Ground connection -1-, in right front wiring harness
- (A42) - Plus connection (fuel gauge), in instrument panel wiring harness


* - Quattro only



Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow


- F1 = Oil Pressure Switch
- F9 = Parking Brake Warning Light Switch
- F34 = Brake Fluid Level Warning Switch
- F66 = Engine Coolant Level (ECL) Warning Switch
- F75 = Hydraulic Fluid Low Level Sensor
- F76 = Engine Coolant Temperature (ECT) Electronic Thermo-switch
- J189 = Auto Check System
- K2 = Generator (GEN) Warning Light
- K14 = Parking Brake Indicator Light
- K19 = Seat Belt Warning Light
- T4h = Wire Connector, 4 Point, black, in engine compartment, right
- T5 = Wire Connector, 5 Point, black, connector station in auxiliary relay panel
- T5c = Wire Connector, 5 Point, on instrument cluster
- T5h = Wire Connector, 5 Point, red, behind instrument panel, left
- T6g = Wire Connector, 6 Point, on instrument cluster
- T6k = Wire Connector, 6 Point, black, behind console
- T6r = Wire Connector, 6 Point, black, behind instrument panel, left

- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26a = Wire Connector, 26 Point, blue, on instrument cluster
- T26b = Wire Connector, 26 Point, white, on instrument cluster (on auto - check - system monitor)
- (83) - Ground connection -1-, in right front wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- (A45) - Wire connection (RPM signal), in instrument panel wiring harness




- F = Brake Light Switch
- J124 = Lamp Control Module, Rear
- M2 = Tail Light, Right
- M4 = Tail Light, Left
- M6 = Turn Signal Light, Left Rear
- M8 = Turn Signal Light, Right Rear
- M9 = Brake Light, Left
- M10 = Brake Light, Right
- M12 = Side Marker Lights, Rear
- M25 = High-Mount Brake Light
- S29 = Fuse in auxiliary fuse holder (Brake Lights)
- T2an = Wire Connector, double, black, in luggage compartment
- T10b = Wire Connector, 10 Point, black, connector station in auxiliary relay panel

- (50) - Ground connection, in luggage compartment, left
- (A18) - Wire connection (54), in instrument panel wiring harness



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- | | |
|---|--|
| <p>F4 = Back-Up Light Switch
 J123 = Lamp Control Module, Front
 L1 = Headlight, Left
 L2 = Headlight, Right
 L13 = High Beam Headlight, Left
 L14 = High Beam Headlight, Right
 L20 = Rear Fog Light Bulb
 M1 = Parking Light, Left
 M3 = Parking Light, Right
 M5 = Turn Signal Light, Left Front
 M7 = Turn Signal Light, Right Front
 M16 = Back-Up Light, Left
 M17 = Back-Up Light, Right
 S6 = Fuse For Parking Lights, Side Marker and Tail Lights, Right, in Fuse Panel
 S7 = Fuse For Parking Lights, Side Marker and Tail Lights, Left, in Fuse Panel
 S8 = Fuse For High Beam Headlight, Right / Headlight High Beam Indicator Light, in Fuse Panel
 S9 = Fuse For High Beam Headlight, Left, in Fuse Panel</p> | <p>S10 = Fuse For Lowbeam Headlight, right, in Fuse Panel
 S11 = Fuse For Lowbeam Headlight, left, in Fuse Panel
 T1f = Wire Connector, single, black, behind instrument panel, left
 T3ac = Wire Connector, 3 Point, white, near headlight, left
 T3ad = Wire Connector, 3 Point, white, near headlight, right
 T4 = Wire Connector, 4 Point, near Headlight, left
 T4a = Wire Connector, 4 Point, near headlight, right
 T6b = Wire Connector, 6 Point, black, in luggage compartment, left
 T10a = Wire Connector, 10 Point, yellow, connector station in auxiliary relay panel</p> <p>(98) - Ground connection, in rear lid wiring harness
 (119) - Ground connection -1-, in headlight wiring harness</p> <p>* - Manual Transmission Only</p> |
|---|--|




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

97-15502

- E1 = Light Switch
- E4 = Headlight Dimmer / Flasher Switch
- E19 = Park Light Switch
- (A3) - Plus connection (58), in instrument panel wiring harness
- (A9) - Plus connection (56b), in instrument panel wiring harness
- (A32) - Plus connection (30), in instrument panel wiring harness
- (A43) - Wire connection (57l), in instrument panel wiring harness
- (A44) - Plus connection (57r), in instrument panel wiring harness

145 Light switch

90 (All models)-USA/Canada
From VIN: 8CPA 000100



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

97-15503


- F5 = Luggage Compartment Light Switch
- S12 = Fuse For Cruise Control/ Electronic Theroswitch/ Auto Check System/ Instrument Cluster/ Interior Light With Delay/ Back-Up Lights/ Servotronic/ Automatic Transmission/ Airbag Control Light/ Coolant Fan Afterrun/ Differential Lock/ Board Computer, in Fuse Panel
- S14 = Fuse For License Light/ Glove Compartment Light/ Engine Compartment Light, in Fuse Panel
- T2w = Wire Connector, double, black, in rear lid lock
- T6 = Wire Connector, 6 Point, black, connector station in auxiliary relay panel
- T6b = Wire Connector, 6 Point, black, in luggage compartment, left
- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- W3 = Luggage Compartment Light
- W6 = Glove Compartment Light
- W27 = Engine Compartment Light
- X = License Plate Light

- (81) - Ground connection -1-, in instrument panel wiring harness
- (98) - Ground connection, in rear lid wiring harness
- (A7) - Plus connection (58 D1), in instrument panel wiring harness
- (A20) - Wire connection (15a), in instrument panel wiring harness

- * - Optional For All Models
- ** - Automatic Transmission Only
- *** - Manual Transmission Only


90 (All models)-USA/Canada
From VIN: 8CPA 000100

Engine compartment light
Glove compartment light **146**



- E2 = Turn Signal Switch
- E3 = Emergency Flasher Switch
- J2 = Emergency Flasher Relay
- S2 = Fuse For Emergency Flasher, in Fuse Panel
- S5 = Fuse For Coolant Fan, in Fuse Panel
- S15 = Fuse For Windshield Wiper And Washer / Washer Nozzle Heaters / Turn Signal Lights / Coolant Fan / Air Conditioning, in Fuse Panel
- T6u = Wire Connector, 6 Point, green, in luggage compartment, right
- T10a = Wire Connector, 10 Point, yellow, connector station in auxiliary relay panel


- (81) - Ground connection -1-, in instrument panel wiring harness
- (A5) - Plus connection (right turn signal), in instrument panel wiring harness
- (A6) - Plus connection (left turn signal), in instrument panel wiring harness



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow


- E22 = Windshield Wiper Intermittent Switch
- F77 = Windshield Washer Fluid Level Warning Switch
- H = Horn Button
- H2 = High Tone Horn
- H7 = Low Tone Horn
- J4 = Dual Horn Relay
- J31 = Washer / Wiper Intermittent Relay
- J39 = Headlight Washer System Relay
- S3 = Fuse For Dual Horns / Heated Seats, in Fuse Panel
- T1i = Wire Connector, single, white, behind instrument panel, left
- T2f = Wire Connector, double, near washer nozzle heater, left
- T2g = Wire Connector, double, near washer nozzle heater, right
- T6 = Wire Connector, 6 Point, black, connector station in auxiliary relay panel
- T6r = Wire Connector, 6 Point, black, behind instrument panel, left
- T10a = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- V = Windshield Wiper Motor
- V5 = Windshield Washer Pump
- V11 = Headlight Washer Pump

- Z20 = Washer Nozzle Heater, Left
- Z21 = Washer Nozzle Heater, Right
- (32) - Ground connection, behind instrument panel, left
- (81) - Ground connection -1-, in instrument panel wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- * - Optional For All Models





- E7 = Fog Light Switch
- E18 = Rear Fog Light Switch
- J5 = Fog Light Relay
- L15 = Ashtray Light
- L22 = Left Front Fog Light Bulb
- L23 = Fog Light Bulb
- L28 = Cigarette Lighter Light
- S1 = Fuse For Fog lights / Rear Fog Lights, in Fuse Panel
- S4 = Fuse For Digital Clock / Luggage Compartment Light / Interior Light, Front / Make-Up-Mirror Lights / Reading Lights / Cigarette Lighters / Bordcomputer / Automatic Climate, in Fuse Panel
- T2l = Wire Connector, double, black, in engine compartment, left
- T2m = Wire Connector, double, black, in engine compartment, right
- T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
- T5a = Wire Connector, 5 point, brown, connector station in auxiliary relay panel
- T10a = Wire Connector, 10 Point, yellow, connector station in auxiliary relay panel

- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- U1 = Cigarette Lighter
- (81) - Ground connection -1-, in instrument panel wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- (199) - Ground connection -3-, in instrument panel wiring harness
- (A19) - Wire connection (58d), in instrument panel wiring harness
- (A23) - Wire connection (30al), in instrument panel wiring harness



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow


- T2e = Wire Connector, double, near interior lights
- T3b = Wire Connector, 3 Point, green, behind instrument panel, left
- T5a = Wire Connector, 5 Point, brown connector station in auxiliary relay panel
- W = Interior Light, Front
- W11 = Reading Light, Left Rear
- W12 = Reading Light, Right Rear
- W13 = Map/Reading Light, Right Front
- W14 = Make-Up Mirror Light, Right
- W20 = Make-Up Mirror Light, Left
- (B1) - Ground connection -1-, in instrument panel wiring harness
- * - Only Make-Up Mirror Light, Left



- F120 = Alarm Switch, Hood
- F121 = Alarm Switch, Driver's Door Handle
- F122 = Alarm Switch, Passenger's Door Handle
- F124 = Alarm / Central Locking Switch, Trunk Lock
- H8 = Alarm Horn
- T1k = Wire Connector, single, blue, behind instrument panel
- T3i = Wire Connector, 3 Point, black, in rear lid
- T3u = Wire Connector, 3 Point, black, in luggage compartment, left
- T6c = Wire Connector, 6 Point, yellow, behind instrument panel, left
- V94 = Central Locking / Alarm System / Interior Light Delay Control Module

- (32) - Ground connection, behind instrument panel, left
- (81) - Ground connection -1-, in instrument panel wiring harness
- (98) - Ground connection, in rear lid wiring harness

- (105) - Ground connection -1-, in central locking system wiring harness
- (Q22) - Wire connection -1-, in rear lid wiring harness
- (Q44) - Wire connection -2-, in tailgate wiring harness
- (S6) - Wire connection (A) -1-, in central locking system wiring harness
- (S7) - Wire connection (A) -2-, in central locking system wiring harness
- * - Manual Transmission Only




97-15509

- E24 = Seat Belt Switch, Left
- F2 = Door Contact Switch, Left Front
- F3 = Door Contact Switch, Right Front
- F10 = Door Contact Switch, Left Rear
- F11 = Door Contact Switch, Right Rear
- F59 = Central Locking System Switch, Driver's Door
- F114 = Central Locking System Switch, Passenger's Door
- G117 = Infrared Central Locking System Sensor, Left
- G118 = Infrared Central Locking System Sensor, Right
- J34 = Seat Belt Warning System Relay
- S17 = Fuse For Automatic Climate Control / Fresh Air Blower, in Fuse Panel
- S19 = Fuse For Central Locking / Alarm System Heated Door Locks, in Fuse Panel
- S20 = Fuse For First Speed Coolant Fan / Coolant Fan Afterrun, in Fuse Panel
- T1v = Wire Connector, single, black, below rear seat, center
- T1y = Wire Connector, single, in driver's door
- T1z = Wire Connector, single, in front passenger's door
- T2ap = Wire Connector, double, in driver's door
- T2aq = Wire Connector, double, in passenger's door

- T2bc = Wire Connector, double, orange, behind instrument panel, left
- T2bd = Wire Connector, double, Black, on Seat Belt switch, left
- T3b = Wire Connector, 3 Point, green, behind instrument Panel, left
- T5a = Wire Connector, 5 Point, brown, connector station in auxiliary relay panel
- T6c = Wire Connector, 6 Point, yellow, in luggage compartment, right
- V94 = Central Locking / Alarm System / Interior Light Delay Control Module
- ⓐ105 - Ground connection -1-, in central locking system wiring harness
- ⓐ199 - Ground connection -3-, in instrument panel wiring harness
- ⓐ26 - Wire connection (driver's door contact switch), in instrument panel wiring harness
- ⓐ11 - Plus connection (30az), in power window / central locking system and door contact switch wiring harness
- ⓐ20 - Wire connection -1- (door contact switch), in power window wiring harness
- * - Manual Transmission Only


30
15
X
31



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

97-15510


- F138 = Airbag Spiral Spring
- J234 = Airbag Control Module
- J312 = Relay For Airbag Control Lamp
- K75 = Airbag Control Light
- N95 = Airbag Igniter - Driver's Side
- T1 = Wire Connector, single, red, behind instrument panel, left
- T2 = Wire Connector, double, red, behind instrument panel
- (32) - Ground connection, behind instrument panel, left
- (109) - Ground connection, in airbag wiring harness
- (T1) - Plus connection -1-, in airbag wiring harness
- (T2) - Plus connection -2-, in airbag wiring harness
- * - Resistor Wire 2,5 Ω



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow


- E15 = Rear Window Defogger Switch
- E43 = Mirror Adjustment Switch
- S16 = Fuse For Rear Window Defogger / Heated Mirrors, in Fuse Panel
- S18 = Fuse For Power Mirrors, in Fuse Panel
- T1e = Wire Connector, single, green, behind instrument panel, left
- T5d = Wire Connector, 5 Point, on right A-pillar, lower part
- T5e = Wire Connector, 5 Point, on left A-pillar, lower part
- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- T10j = Wire Connector, 10 Point, on heated mirror, left
- T10k = Wire Connector, 10 Point, on heated mirror, right
- V17 = Driver's Side Mirror Adjustment Motor
- V25 = Passenger's Side Mirror Adjustment Motor
- Z1 = Rear Window Defogger (Heat Element)
- Z4 = Driver's Side Heated Mirror
- Z5 = Passenger's Side Heated Mirror

- (32) - Ground connection, behind instrument Panel, left
- (81) - Ground connection -1-, behind instrument Panel wiring harness
- (107) - Ground connection, in outside mirrors wiring harness



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow


- E40 = Window Switch, Left Front
- J139 = Power Window Control Module
- S43 = Power Window Circuit Breaker, in Adapter C
- T1x = Wire Connector, single, green, behind instrument panel ,left
- T2a = Wire Connector, double, in driver's door
- T2c = Wire Connector, double, white, behind instrument panel, left
- V14 = Window Motor, Left
- (32) - Ground connection, behind instrument panel, left
- (89) - Ground connection -1-, in power window wiring harness
- (Q10) - Plus connection (87), in power window / central locking system and door contact switch wiring harness
- * - Fuses in Fuse Adapter C are installed in any free position and are not allocated any specific position



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- E39 = Window Lockout Switch
- E41 = Window Switch, Right Front
- E52 = Left Rear Window Switch, (in Door)
- E53 = Left Rear Window Switch, (in Console)
- E54 = Right Rear Window Switch, (in Door)
- E55 = Right Rear Window Switch, (in Console)
- E107 = Right Front Window Switch, (in Passenger's Door)
- V15 = Window Motor, Right
- V26 = Window Motor, Left Rear Door
- V27 = Window Motor, Right Rear Door

- (89) - Ground connection -1-, in power window wiring harness
- (Q9) - Wire connection, in power window wiring harness
- (Q10) - Plus connection (87), in power window/central locking system and door contact switch wiring harness




- G44 = ABS Wheel Speed Sensor, Right Rear
- G45 = ABS Wheel Speed Sensor, Right Front
- G46 = ABS Wheel Speed Sensor, Left Rear
- G47 = ABS Wheel Speed Sensor, Left Front
- J104 = ABS Control Module
- J105 = ABS Return Flow Pump Relay
- J106 = ABS Solenoid Valve Relay
- J156 = ABS Combination Relay
- N55 = ABS Hydraulic Unit
- N137 = ABS Inlet / Outlet Valve, Left Front
- N138 = ABS Inlet / Outlet Valve, Right Front
- N139 = ABS Inlet / Outlet Valve, Left Rear
- N140 = ABS Inlet / Outlet Valve, Right Rear
- S31 = Fuse For ABS / Differential Lock, in Fuse Panel
- T2a = Wire Connector, double, below rear seat, right
- T2b = Wire Connector, double, in engine compartment, right
- T2c = Wire Connector, double, below rear seat, left
- T2d = Wire Connector, double, in engine compartment, left

- T10d = Wire Connector, 10 Point, blue, connector station in auxiliary relay panel
- V39 = ABS Return Flow Pump
- (22) - Ground connection, on hydraulic unit
- (32) - Ground connection, behind instrument panel, left
- (100) - Ground connection -1-, in ABS wiring harness
- (A57) - Wire connection (ABS), in instrument panel wiring harness
- (J1) - Plus connection (30), in ABS wiring harness

30 _____ 30
 15 _____ 15
 X _____ X
 31 _____ 31




Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow



97-15515

- E45 = Cruise Control Switch
- F36 = Vacuum Vent Valve, Clutch
- F47 = Vacuum Vent Valve, Brake
- J213 = Cruise Control, Control Module
- J217 = Alarm System Relay
- S30 = Fuse For Cruise Control (Automatic Transmission), in Fuse Panel
- T3f = Wire Connector, 3 Point, blue, behind instrument panel
- T4d = Wire Connector, 4 Point, black, behind instrument panel
- T6v = Wire Connector, 6 Point, blue, behind instrument panel, left
- T10c = Wire Connector, 10 Point, green, connector station in auxiliary relay panel
- V18 = Cruise Control Vacuum Pump
- (32) - Ground connection, behind instrument panel, left
- (199) - Ground connection -3-, in instrument panel wiring harness
- (A27) - Wire connection (speed signal), in Instrument panel wiring harness
- * - Manual Transmission Only
- ** - Automatic Transmission Only



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

J236 = Servotronic Control Module

N119 = Servotronic Solenoid Valve

R = Radio

T4i = Wire Connector, 4 Point, green, behind instrument panel


T5f = Wire Connector, 5 Point, blue, behind instrument panel

(32) - Ground connection, behind instrument panel, left

(81) - Ground connection -1-, in instrument panel wiring harness

(A46) - Plus connection (30-from Radio), in instrument panel wiring harness

30 _____ 30
 15 _____ 15
 X _____ X
 31 _____ 31




Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- F22 = Oil Pressure Switch (0,3 bar)
- G8 = Oil Temperature Sensor
- G9 = Oil Temperature Gauge
- G10 = Oil Pressure Sensor
- G11 = Oil Pressure Gauge
- G14 = Voltmeter
- J166 = Instrument Lighting Booster
- L50 = Center Rear Ashtray Light
- T2s = Wire Connector, double, brown, behind console
- T4h = Wire Connector, 4 Point, black, in engine compartment right
- T6w = Wire Connector, 6 Point, white, behind console

(199) - Ground connection -3-, in instrument panel wiring harness

97-15517

Fuse / Relay Panel (Left Side Plenum Tray)



Relay location


90 CS-USA/Canada
90 CS Quattro Sport-USA

From VIN: 8CPA 000100

8-Way power front driver's seat
(w/o memory)


162

Auxiliary Relay Panel With Connector Station



Relay location

Auxiliary Relay Panel, Rear




Relay location

163 8-Way power front driver's seat
(w/o memory)

From VIN: 8CPA 000100

90 CS-USA/Canada
90 CS Quattro Sport-USA



97-15577

- E61 = Driver Seat Fore / Aft Adjusting Switch
- E62 = Driver Seat Front Height Adjusting Switch
- E63 = Driver Seat Rear Height Adjusting Switch
- E96 = Driver Backrest Adjustment Switch
- S44 = Fuse For Memory Seat Adjusting Circuit Breaker, in Adapter C
- T60 = Wire Connector, 6 Point, brown, below driver's seat
- V28 = Driver's Seat Fore / Aft Adjusting Motor
- V29 = Driver's Seat Front Height Adjusting Motor
- V30 = Driver's Seat Rear Height Adjusting Motor
- V45 = Driver's Backrest Adjusting Motor

- (32) - Ground connection, in instrument panel, left
- (96) - Ground connection -1-, in power seat wiring harness

- * - With Heated Front Seats
- ** - Without Heated Front Seats


90 CS—USA/Canada
90 CS Quattro Sport—USA

From VIN: 8CPA 000100

8-Way power front driver's seat
(w/o memory)


164

Fuse / Relay Panel (Left Side Plenum Tray)




Relay location

Auxiliary Relay Panel With Connector Station




Relay location

Auxiliary Relay Panel, Rear



Relay location


22 - Electronic Differential Lock Cot-Off Relay, J263



97-15564

- F = Brake Light Switch
 G44 = ABS Wheel Speed Sensor, Right Rear
 G45 = ABS Wheel Speed Sensor, Right Front
 G46 = ABS Wheel Speed Sensor, Left Rear
 G47 = ABS Wheel Speed Sensor, Left Front
 J104 = ABS Control Module (w/EDL)
 S29 = Fuse For Brake Lights, in Fuse Panel
 S31 = Fuse For ABS / Differential Lock, in Fuse Panel
 T2a = Wire Connector, double, below rear seat, right
 T2b = Wire Connector, double, in engine compartment, right
 T2c = Wire Connector, double, below rear seat, left
 T2d = Wire Connector, double, in engine compartment, left
 T10d = Wire Connector, 10 Point, blue, connector station in auxiliary relay panel
- (32) - Ground connection, behind instrument panel, left
 (100) - Ground connection -1-, in ABS wiring harness


- (A2) - Plus connection (15), in instrument panel wiring harness
 (A18) - Wire connection (54), in instrument panel wiring harness
 (A32) - Plus connection (30), in instrument panel wiring harness



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- D = Ignition / Starter Switch
- F113 = ABS Acceleration Switch
- J104 = ABS Control Module (w/EDL)
- J105 = ABS Return Flow Pump Relay
- J106 = ABS Solenoid Valve Relay
- J189 = Auto Check System
- J263 = Electronic Differential Lock Cot-Off Relay
- N55 = ABS Hydraulic Unit
- N58 = ABS Solenoid Valve, Right Front
- N59 = ABS Solenoid Valve, Left Front
- N77 = ABS Solenoid Valve, Rear
- T10d = Wire Connector, 10 Point, blue, connector station in auxiliary relay panel
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- V39 = ABS Return Flow Pump
- (22) - Ground connection, on hydraulic unit
- (100) - Ground connection -1-, in ABS wiring harness

- (A17) - Wire connection (61), in instrument panel wiring harness
- (J1) - plus connection (30), in ABS wiring harness




Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- E121 = Rear Differential Lock Switch
- F100 = Differential Lock Switch, Rear
- G21 = Speedometer
- G22 = Vehicle Speed Sensor (VSS), Speedometer
- J145 = Display Unit
- J187 = Differential Lock Control Module
- K46 = Rear Differential Lock Indicator Light
- K47 = ABS Warning Light
- K81 = Differential Lock Indicator Light
- L10 = Instrument Cluster Light
- L55 = Differential Lock Switch Light
- L61 = Differential Lock Switch Light
- T2a1 = Wire Connector, double, white, below rear seat, left
- T10d = Wire Connector, 10 Point, blue, connector station in auxiliary relay panel
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26a = Wire Connector, 26 Point, blue, on instrument cluster

- (81) - Ground connection -1-, in instrument panel wiring harness
- (100) - Ground connection -1-, in ABS wiring harness
- A19 - Wire connection (58d), in instrument panel wiring harness
- A20 - Wire connection (15a), in instrument panel wiring harness
- A27 - Wire connection (speed signal), in instrument panel wiring harness
- A57 - Wire connection (ABS), in instrument panel wiring harness

Fuse / Relay Panel (Left Side Plenum Tray)




Relay location

171 AM/FM stereo radio with 6 speakers


90 (All models)-USA/Canada
From VIN: 8CPA 000100

Auxiliary Relay Panel With Connector Station




Relay location

Auxiliary Relay Panel, Rear




Relay location



- D = Ignition / Starter Switch
- E15 = Rear Window Defogger Switch
- E20 = Instrument Panel Light Dimmer Switch
- J34 = Seat Belt Warning System Relay
- J189 = Auto-Check-System
- R = Radio
- R11 = Antenna
- R24 = Antenna Amplifier
- T11 = Wire Connector, single, red, in luggage compartment, left
- T1af = Wire Connector, single, red, in luggage compartment, right
- T6c = Wire Connector, 6 Point, yellow, behind instrument panel, left
- T6k = Wire Connector, 6 Point, black, behind console
- T8b = Wire Connector, 8 Point, on Radio
- T10b = Wire Connector, 10 Point, brown, connector station on auxiliary relay panel
- T10h = Wire Connector, 10 Point, red, on Radio
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26b = Wire Connector, 26 Point, white, on instrument cluster (Auto Check System With Display)

- V94 = Central Locking / Alarm System / Interior Light Delay Control Module
- Z24 = Rear Window Defogger With Window Antenna
- (81) - Ground connection -1-, in instrument panel wiring harness
- (A19) - Wire connection (58d), in instrument panel wiring harness
- (A21) - Wire connection (86s), in instrument panel wiring harness
- (A46) - Wire connection (30-from radio), in instrument panel wiring harness
- * - Located in Rear D-Pillar, Right
- ** - Located in Rear D-Pillar, Left




- R = Radio
- R2 = Speaker, Left Front
- R3 = Speaker, Right Front
- R14 = Tweeter, Left Rear
- R15 = Woofer, Left Rear
- R16 = Tweeter, Right Rear
- R17 = Woofer, Right Rear
- T2af = Wire Connector, double, on Tweeter, Right Rear
- T2ag = Wire Connector, double, on Tweeter, Left Rear
- T5m = Wire Connector, 5 Point, black, on Woofer, Left Rear
- T5n = Wire Connector, 5 Point, black, on Woofer, Right Rear
- T5r = Wire Connector, 5 Point, in left rear door
- T5s = Wire Connector, 5 Point, in right rear door
- T6k = Wire Connector, 6 Point, black, behind console
- T8b = Wire Connector, 8 Point, on Radio
- T8c = Wire Connector, 8 Point, on Radio
- T10h = Wire Connector, 10 Point, red, on Radio
- T26 = Wire Connector, yellow, on instrument cluster
- Y2 = Digital Clock

- (199) - Ground connection -3-, in instrument panel wiring harness
- (A23) - Wire connection (30a), in instrument panel wiring harness
- (V1) - Plus connection (30), in rear speaker wiring harness

**This page
intentionally
left blank**


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

- 2** - Second Speed Coolant Fan Control (FC) Relay, J101
- 3** - Coolant FC (Fan Control) Relay, J26


Auxiliary Relay Panel With Connector Station




Relay location

- 4** - A/C Compressor Clutch Relay, J44
- 18** - Third Speed Coolant FC (Fan Control) Relay, J135

Auxiliary Relay Panel, Rear




Relay location



- F18 = Coolant Fan Control (FC) Theroswitch
- F23 = A/C Refrigerant High Pressure Switch
- F54 = Coolant Fan Control (FC) Theroswitch
- J101 = Second Speed Coolant Fan Control (FC) Relay

- (127) - Ground connection -1-, in A/C compressor wiring harness
- (L1) - Plus connection (75), in A/C wiring harness
- (L5) - Wire connection -1-, in evaporator housing wiring harness

- * - until October 1992
- ** - from October 1992
- *** - Relay are installed in any free position and are not allocated any specific position




97-16111


- J26 = Coolant Fan Control (FC) Relay
- J135 = Third Speed Coolant Fan Control (FC) Relay
- N39 = Coolant Fan Control (FC) Series Resistance
- S42 = Fuse For Coolant Fan, in Adapter B
- T6u = Wire Connector, 6 Point, green, behind instrument panel, left
- V7 = Coolant Fan

- (11) - Ground connection, in battery box
- (32) - Ground connection, behind instrument panel, left
- (127) - Ground connection -1-, in A/C compressor wiring harness
- (L1) - Plus connection (75), in A/C wiring harness
- (L5) - Wire connection -1-, in evaporator housing wiring harness

- * - until October 1992
- ** - from October 1992




- | | |
|--|--|
| E1 = Light Switch | T26 = Wire Connector, 26 Point, yellow, on instrument cluster |
| E87 = A/C Control Head | V2 = Fresh Air Blower |
| F73 = A/C Refrigerant Low Pressure Switch | Y2 = Digital Clock |
| F76 = Engine Coolant Temperature (ECT) Electronic Thermo-switch | (97) - Ground connection -1-, in A/C wiring harness |
| G5 = Tachometer | (127) - Ground connection -1-, in A/C compressor wiring harness |
| G111 = A/C Compressor Speed Sensor | (A3) - Plus connection (58), in instrument panel wiring harness |
| J126 = Fresh Air Blower Control Module | (A20) - Wire connection (15a), in instrument panel wiring harness |
| J192 = MFI Engine Control Module (ECM) | (A23) - Wire connection (30a), in instrument panel wiring harness |
| N63 = Fresh Air / Recirculating Flap Two-Way Valve | (A45) - Wire connection (RPM signal), in instrument panel wiring harness |
| T2z = Wire Connector, double, white, in Plenum, Near Relay Panel (Data Link Connector) | (L4) - Wire connection (75a), in A/C wiring harness |
| T2am = Wire Connector, double, green, near compressor | (L9) - Wire connection -1-, in A/C wiring harness |
| T2at = Wire Connector, double, black, behind instrument panel, center | K - Wire Distributer For Data Link Connector(DLC); Terminal K |
| T3c = Wire Connector, 3 Point, brown, behind instrument panel, center | |
| T5g = Wire Connector, 5 Point, green, connector station in auxillary relay panel | |
| T5h = Wire Connector, 5 Point, red, behind instrument panel, left | |
| T5o = Wire Connector, 5 Point, red, behind instrument panel, center | |
| T6q = Wire Connector, 6 Point, red, behind instrument panel, center | |
| T10e = Wire Connector, 10 Point, red, behind instrument panel, center | |



Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- | | |
|---|--|
| E87 = A/C Control Head | (81) - Ground connection -1-, in instrument panel wiring harness |
| G5 = Tachometer | (97) - Ground connection -1-, in A/C wiring harness |
| G92 = Temperature Regulator Flap Motor Potentiometer | (112) - Ground connection -2-, in A/C wiring harness |
| G112 = Central Flap Motor Potentiometer | (188) - Ground connection -3-, in A/C wiring harness |
| G113 = Back Pressure Flap Motor Potentiometer | (A45) - Wire connection (RPM signal), in instrument panel wiring harness |
| G114 = Footwell / Defrost Flap Motor Potentiometer | (L31) - Wire connection (5 Volts), in A/C wiring harness |
| J217 = Transmission Control Module (TCM) | |
| T1m = Wire Connector, single, red, behind instrument panel, left | |
| T3c = Wire Connector, 3 Point, brown, behind instrument panel, center | |
| T5o = Wire Connector, 5 Point, red, behind instrument panel, center | |
| T6q = Wire Connector, 6 Point, behind instrument panel, center | |
| T26 = Wire Connector, 26 Point, yellow, on instrument cluster | |
| V68 = Temperature Regulator Flap Motor | |
| V70 = Central Air Flap Motor | |
| V71 = Air Flow Flap Motor | |
| V85 = Footwell / Defrost Flap Motor | |




- E20 = Instrument Panel Light Dimmer Switch
 E87 = A/C Control Head
 F118 = A/C Refrigerant High Pressure Switch
 G17 = Outside Air Temperature Sensor
 G21 = Speedometer
 G56 = Interior Temperature Sensor; in instrument panel
 G86 = Interior Temperature Sensor; in Headliner
 G89 = Fresh Air Intake Duct Temperature Sensor
 G106 = Outside Air Temperature Display
 J44 = A/C Clutch Relay
 J201 = Protection Diode
 N25 = A/C Clutch
 T1n = Wire Connector, single, green, near compressor
 T2t = Wire Connector, double, brown, behind instrument panel, left
 T2u = Wire Connector, double, red, behind instrument panel, left
 T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
 T5g = Wire Connector, 5 Point, green, connector station in auxiliary relay panel
 T5l = Wire Connector, 5 Point, yellow, on instrument cluster
 T5o = Wire Connector, 5 Point, red, behind instrument panel, center
 T6q = Wire Connector, 6 Point, red, behind instrument panel, center

- T10e = Wire Connector, 10 Point, red, behind instrument panel, center
 T26 = Wire Connector, 26 Point, yellow, on instrument cluster
 T26a = Wire Connector, 26 Point, blue, on instrument cluster
 V42 = Fan For Interior Temperature Sensor

- (29) - Ground connection, near compressor
 (112) - Ground connection -2-, in A/C wiring harness
 (199) - Ground connection -2-, in instrument panel wiring harness
 (A19) - Wire connection (58d), in instrument panel wiring harness
 (A27) - Wire connection (speed signal), in instrument panel wiring harness
 (A34) - Wire connection (75x), in instrument panel wiring harness
 (L2) - Wire connection, in A/C wiring harness

- * - until October 1992
 ** - from October 1992


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

11 - Coolant FC (Fan Control) Relay, J26


Auxiliary Relay Panel With Connector Station




Relay location

- 4** - A/C Compressor Clutch Relay, J44
- 18** - Second Speed Coolant FC (Fan Control) Relay, J101

Auxiliary Relay Panel, Rear




Relay location



- F18 = Coolant Fan Control (FC) Thermoswitch
- F23 = A/C Refrigerant High Pressure Switch
- F54 = Coolant Fan Control (FC) Thermoswitch
- G111 = A/C Compressor Speed Sensor
- J26 = Coolant Fan Control (FC) Relay
- J101 = Second Speed Coolant Fan Control (FC) Relay
- N39 = Coolant Fan Control (FC) Series Resistance
- S42 = Fuse For Coolant Fan, in Adapter B
- T2am = Wire Connector, double, green, near compressor
- T6u = Wire Connector, 6 Point, green, behind instrument panel, left
- V7 = Coolant Fan


- (11) - Ground connection, in battery box
- (32) - Ground connection, behind instrument panel, left
- (127) - Ground connection -1-, in A/C compressor wiring harness
- (L1) - Plus connection (75), in A/C wiring harness



Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- E1 = Light Switch
- E87 = A/C Control Head
- F73 = A/C Refrigerant Low Pressure Switch
- F76 = Engine Coolant Temperature (ECT) Electronic Thermoswitch
- G5 = Tachometer
- J126 = Fresh Air Blower Control Module
- J192 = MFI Engine Control Module (ECM)
- N63 = Fresh Air / Recirculating Flap Two-Way Valve
- T2z = Wire Connector, double, white, in Plenum, Near Relay Panel (Data Link Connector)
- T2at = Wire Connector, double, black, behind instrument panel, center
- T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
- T5h = Wire Connector, 5 Point, red, behind instrument panel, left
- T5o = Wire Connector, 5 Point, red, behind instrument panel, center
- T6q = Wire Connector, 6 Point, red, behind instrument panel, center
- T10e = Wire Connector, 10 Point, red, behind instrument panel, center
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- V2 = Fresh Air Blower
- Y2 = Digital Clock

- (97) - Ground connection -1-, in A/C wiring harness
- (A3) - Plus connection (58), in instrument panel wiring harness
- (A20) - Wire connection (15a), in instrument panel wiring harness
- (A23) - Wire connection (30al), in instrument panel wiring harness
- (A45) - Wire connection (RPM signal), in instrument panel wiring harness
- (L4) - Wire connection (75al), in A/C wiring harness
- (L9) - Wire connection -1-, in A/C wiring harness
- K - Wire Distributer For Data Link Connector(DLC); Terminal K




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

97-15580

- E87 = A/C Control Head
- G5 = Tachometer
- G92 = Temperature Regulator Flap Motor Potentiometer
- G112 = Central Flap Motor Potentiometer
- G113 = Back Pressure Flap Motor Potentiometer
- G114 = Footwell / Defrost Flap Motor Potentiometer
- J217 = Transmission Control Module (TCM)
- T1m = Wire Connector, single, red, behind instrument panel, left
- T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
- T5o = Wire Connector, 5 Point, red, behind instrument panel, center
- T6q = Wire Connector, 6 Point, behind instrument panel, center
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- V68 = Temperature Regulator Flap Motor
- V70 = Central Air Flap Motor
- V71 = Air Flow Flap Motor
- V85 = Footwell / Defrost Flap Motor

- (81) - Ground connection -1-, in instrument panel wiring harness
- (97) - Ground connection -1-, in A/C wiring harness
- (112) - Ground connection -2-, in A/C wiring harness
- (188) - Ground connection -3-, in A/C wiring harness
- (A45) - Wire connection (RPM signal), in instrument panel wiring harness
- (L31) - Wire connection (5 Volts), in A/C wiring harness


* - Automatic Transmission Only



97-15581

- | | |
|---|---|
| <p>E20 = Instrument Panel Light Dimmer Switch
 E87 = A/C Control Head
 F118 = A/C Refrigerant High Pressure Switch
 G17 = Outside Air Temperature Sensor
 G21 = Speedometer
 G56 = Interior Temperature Sensor; in instrument panel
 G86 = Interior Temperature Sensor, in Headliner
 G89 = Fresh Air Intake Duct Temperature Sensor
 G106 = Outside Air Temperature Display
 J44 = A/C Clutch Relay
 J201 = Protection Diode
 N25 = A/C Clutch
 T1n = Wire Connector, single, green, near compressor
 T2t = Wire Connector, double, brown, behind instrument panel, left
 T2u = Wire Connector, double, red, behind instrument panel, left
 T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
 T5g = Wire Connector, 5 Point, green, connector station in auxiliary relay panel
 T5l = Wire Connector, 5 Point, yellow, on instrument cluster
 T5o = Wire Connector, red, behind instrument panel, center
 T6q = Wire Connector, 6 Point, red, behind instrument panel, center</p> | <p>T10e = Wire Connector, 10 Point, red, behind instrument panel, center
 T26 = Wire Connector, 26 Point, yellow, on instrument cluster
 T26a = Wire Connector, 26 Point, blue, on instrument cluster
 V42 = Fan For Interior Temperature Sensor</p> <p>(29) - Ground connection, near compressor
 (112) - Ground connection -2-, in A/C wiring harness
 (199) - Ground connection -2-, in instrument panel wiring harness
 (A19) - Wire connection (58d), in instrument panel wiring harness
 (A27) - Wire connection (speed signal), in instrument panel wiring harness
 (A34) - Wire connection (75x), in instrument panel wiring harness
 (L2) - Wire connection, in A/C wiring harness</p> |
|---|---|


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

- 8 - Open (Automatic Transmission)


Auxiliary Relay Panel With Connector Station




Relay location

- 1** - PNP (Park/Neutral Position) Relay, J226
- 2** - Shift Lock Control Module, J226
- 8** - Automatic Transmission Console Light Switch-Over Relay, J307
- 11** - Program Switch Light Relay, J300

Auxiliary Relay Panel, Rear




Relay location



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- E45 = Cruise Control Switch
- E87 = A/C Control Head
- E122 = Transmission Range (TR) Program Switch
- F = Brake Light Switch
- G38 = Transmission Vehicle Speed Sensor (VSS)
- G93 = Transmission Fluid Temperature Sensor
- J153 = A/C Clutch Control Module
- J217 = Transmission Control Module (TCM)
- N88 = Solenoid Valve 1
- N89 = Solenoid Valve 2
- N90 = Solenoid Valve 3
- N91 = Solenoid Valve 4
- N92 = Solenoid Valve 5
- N93 = Solenoid Valve 6
- N94 = Solenoid Valve 7
- S29 = Fuse For Brake Lights, In Fuse Panel
- S30 = Fuse For Cruise Control (Automatic Transmission), In Fuse Panel
- T1m = Wire Connector, single, red, behind Instrument panel, left
- T2z = Wire Connector, double, white, In Plenum Near Relay Panel (Data Link Connector)

- T4e = Wire Connector, 4 Point, black, behind instrument panel
- T5o = Wire Connector, 5 Point, red, behind Instrument panel, center
- T6h = Wire Connector, 6 Point, black, behind instrument panel
- T10c = Wire Connector, 10 Point, green, connector station in auxiliary relay panel
- (17) - Ground connection, on Intake manifold
- (114) - Ground connection, In automatic transmission wiring harness
- (150) - Ground connection, In automatic transmission (AG4) wiring harness
- (A18) - Wire connection (54), In Instrument panel wiring harness
- (A32) - Plus connection (30), In Instrument panel wiring harness
- K - Wire Distributor For Data Link Connector (DLC); Terminal K
- * - Automatic Climate Control Only
- ** - Manual Air Conditioning Only




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

97-15570


- B = Battery
 - D = Ignition / Starter Switch
 - F8 = Kick Down Switch
 - G5 = Tachometer
 - G21 = Speedometer
 - J192 = MFI Engine Control Module (ECM)
 - J217 = Transmission Control Module (TCM)
 - J221 = Shift Lock Control Module
 - N110 = Shift Lock Solenoid
 - T1h = Wire Connector, single, red, behind instrument panel, left
 - T2v = Wire Connector, double, white, behind instrument panel
 - T6h = Wire Connector, 6 Point, black, behind instrument panel
 - T10c = Wire Connector, 10 Point, green, connector station in auxiliary relay panel
 - T26 = Wire Connector, 26 Point, yellow, on instrument cluster
 - T26a = Wire Connector, 26 Point, blue, on instrument cluster
 - V94 = Central Locking/Alarm System/Interior Light Delay Control Module
- (83) - Ground connection -1-, In right front wiring harness
 - (150) - Ground connection -1-, In automatic transmission (AG4) wiring harness
 - (A27) - Wire connection (speed signal), In instrument panel wiring harness
 - (A41) - Plus connection (50), In instrument panel wiring harness
 - (A45) - Plus connection (RPM signal), In instrument panel wiring harness
 - (U2) - Wire connection -1- (15), In automatic transmission wiring harness

30
15
X
31



Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

- F125 = Multi-Funktion Transmission Range (TR) Switch
- J217 = Transmission Control Module (TCM)
- J226 = Park/Neutral Position (PNP) Relay
- M16 = Back-Up Light, Left
- M17 = Back-Up Light, Right
- T1f = Wire Connector, single, black, behind instrument panel, left
- T5 = Wire Connector, 5 Point, black, connector station in auxiliary relay panel
- T10c = Wire Connector, 10 Point, green, connector station in auxiliary relay panel
- (32) - Ground connection, behind instrument panel, left
- (150) - Ground connection, in automatic transmission (AG4) wiring harness
- (U2) - Ground connection -1- (15), In automatic transmission wiring harness




97-15572

- E20 = Instrument Panel Light Dimmer Switch
 J201 = Protection Diode
 J300 = Program Switch Illumination Relay
 J307 = Selector Lever Light Relay
 K2 = Generator (GEN) Warning Light
 L19 = Automatic Transmission Console Light
 S4 = Fuse For Digital Clock / Luggage Compartment Light/
 Interior Light, Front /Make-Up Mirror Lights/ Reading
 Lights / Cigarette Lighters / Boardcomputer / Automatic
 Climate Control / Radio / Auto Check System, In Fuse Panel
 S12 = Fuse For Cruise Control / Electronic Thermoswitch / Auto
 Check System / Instrument Cluster / Interior Light With
 Delay / Back-Up Lights / Servotronic / Boardcomputer /
 Automatic Transmission / Airbag Control Light / Coolant
 Fan Afterrun / Differential Lock, In Fuse Panel
 S14 = Fuse For License Plate Light / Glove Compartment Light /
 Engine Compartment Light, In Fuse Panel
 T51 = Wire Connector, 5 Point, black, behind instrument panel
 T10c = Wire Connector, 10 Point, green, connector station in
 auxiliary relay panel

- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
 W6 = Glove Compartment Light
 Y6 = Transmission Range (TR) Selector Lever Display
 (150) - Ground connection, In automatic transmission
 (AG4) wiring harness
 (199) - Ground connection -3-, in instrument panel wiring harness
 (A3) - Plus connection (58), in instrument panel wiring harness
 (A7) - Plus connection (58D1), in instrument panel wiring harness
 (A17) - Plus connection (61), in instrument panel wiring harness
 (A19) - Plus connection (58d), in instrument panel wiring harness
 (A20) - Plus connection (15a), in instrument panel wiring harness
 (A23) - Plus connection (30a), in instrument panel wiring harness


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

- 1** - Fog Light Relay, J5
- 5** - Load Reduction Relay, J59


Auxiliary Relay Panel With Connector Station




Relay location

- 10** - Daytime Running Lights Relay, J90
- 15** - Lamp Control Module, Front, J123 (Auto Check System Only)

Auxiliary Relay Panel, Rear




Relay location



- F = Brake Light Switch
 G = Fuel Level Sensor
 J124 = Lamp Control Module, Front
 J189 = Auto Check System
 M2 = Tail Light, Right
 M4 = Tail Light, Left
 M6 = Turn Signal Light, Left Rear
 M8 = Turn Signal Light, Right Rear
 M9 = Brake Light, Left
 M10 = Brake Light, Right
 M12 = Side Marker Lights, Rear
 M25 = High-Mount Brake Light
 S12 = Fuse For Cruise Control / Electronic Theroswitch / Auto Check System / Instrument Cluster / Interior Light With Delay / Back-Up Lights / Servotronic / Automatic Transmission / Airbag / Control Light / Coolant Fan Afterrun / Differential Lock / Boardcomputer, in Fuse Panel
 T2an = Wire Connector, double, black, in luggage compartment
 T6b = Wire Connector, 6 Point, black, in luggage compartment, left

- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
 T26b = Wire Connector, 26 Point, white, on instrument cluster (Auto Check System With Delay)
 (32) - Ground connection, behind instrument panel, left
 (98) - Ground connection, in rear lid wiring harness
 (A18) - Wire connection (54), in instrument panel wiring harness
 (A20) - Wire connection (15a), in instrument panel wiring harness



Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

97-15588


- F4 = Back-Up Light Switch
- J123 = Lamp Control Module, Front
- J189 = Auto Check System
- L1 = Headlight, Left
- L2 = Headlight, Right
- L13 = High Beam Headlight, Left
- L14 = High Beam Headlight, Right
- M1 = Parking Light, Left
- M3 = Parking Light, Right
- M5 = Turn Signal Light, Left Front
- M7 = Turn Signal Light, Right Front
- M16 = Back-Up Light, Left
- M17 = Back-Up Light, Right
- S6 = Fuse For Parking Lights, Side Marker and Tail Lights, Right, in Fuse Panel
- S7 = Fuse For Parking Lights, Side Marker and Tail Lights, Left, in Fuse Panel
- S8 = Fuse For High Beam Headlight, Right / Headlight High Beam Indicator Light, in Fuse Panel
- S9 = Fuse For High Beam Headlight, Left, in Fuse Panel
- S10 = Fuse For Lowbeam Headlight, Right, in Fuse Panel

- S11 = Fuse For Lowbeam Headlight, Left in Fuse Panel
- T1f = Wire Connector, single, black, behind instrument panel, left
- T3ac = Wire Connector, 3 Point, white, near headlight, left
- T3ad = Wire Connector, 3 Point, white, near headlight, right
- T4 = Wire Connector, 4 Point, near headlight, left
- T4a = Wire Connector, 4 Point, near headlight, right
- T6b = Wire Connector, 6 Point, black, in luggage compartment, left
- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- T26b = Wire Connector, 26 Point, white, on instrument cluster (Auto Check System With Delay)
- (98) - Ground connection, in rear lid wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- (A5) - Plus connection (right turn signal), in instrument panel wiring harness
- (A6) - Plus connection (left turn signal), in instrument panel wiring harness
- (A9) - Plus connection (56b), in instrument panel wiring harness
- * - Auto Check System Only
- *** - Manual Transmission Only

90 S, 90 S Quattro, 90 CS
Canada only

From VIN: 8CPA 000100

Daytime running lights **198**




- D = Ignition / Starter Switch
- E1 = Light Switch
- E4 = Headlight Dimmer / Flacher Switch
- E19 = Parklight Switch
- J59 = Load Reduction Relay
- J90 = Daytime Running Lights Relay
- N74 = Series Resistance Wiring
- T2n = Wire Connector, double, brown, behind instrument panel, left

- (199) - Ground connection -3-, in front light wiring harness
- (A32) - Plus connection (30), in instrument panel wiring harness
- (A33) - Plus connection (75), in instrument panel wiring harness
- (A43) - Plus connection (57l), in instrument panel wiring harness
- (A44) - Plus connection (57r), in instrument panel wiring harness

199 Daytime running lights

From VIN: 8CPA 000100

90 S, 90 S Quattro, 90 CS
Canada only




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

97-15590

- | | |
|--|---|
| E7 = Fog Light Switch | T26 = Wire Connector, 26 Point, yellow, on instrument cluster |
| E18 = Rear Fog Light Switch | T26a = Wire Connector, 26 Point, blue, on instrument cluster |
| E20 = Instrument Panel Light Dimmer Switch | X = License Plate Light |
| J5 = Fog Light Relay | (81) - Ground connection -1-, in instrument panel wiring harness |
| K1 = Headlight High Beam Indicator Light | (98) - Ground connection , in rear lid wiring harness |
| L20 = Rear Fog Light Bulb | (119) - Ground connection -1- , in headlight wiring harness |
| L22 = Left Front Fog Light Bulb | (A3) - Plus connection (58), in instrument panel wiring harness |
| L23 = Fog Light, Right | (A7) - Plus connection (58D1), in instrument panel wiring harness |
| S1 = Fuse For Fog Lights / Rear Fog Lights, in Fuse Panel | (A19) - Wire connection (58d), in instrument panel wiring harness |
| S14 = Fuse For License Plate Light / Glove Compartment Light / Engine Compartment Light, in Fuse Panel | |
| S23 = Fuse For Daytime Running Lights, in Fuse Panel | |
| T2l = Wire Connector, double, black, in engine compartment, left | |
| T2m = Wire Connector, double, black, in engine compartment, right | |
| T26 = Wire Connector, 6 Point, black, in luggage compartment, left | |
| T6b = Wire Connector, 10 Point, black, connector station in auxiliary relay panel | |
| T10a = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel | |
| T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel | |


**This page
intentionally
left blank**

Fuse / Relay Panel (Left Side Plenum Tray)




Relay location

Auxiliary Relay Panel With Connector Station




Relay location

Auxiliary Relay Panel, Rear



Relay location




Wiring Color Code
ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = gray
li = violet
ge = yellow

97-15586

- E125 = Heated Door Lock Switch, Left
- E126 = Heated Door Lock Switch, Right
- J210 = Heated Door Lock Control Module, Left
- J211 = Heated Door Lock Control Module, Right
- S19 = Central Locking / Alarm System Heated Door Locks, in Fuse Panel
- T1aa = Wire Connector, single, behind instrument panel
- Z22 = Door Lock Heater, Left
- Z23 = Door Lock Heater, Right


(32) - Ground connection, behind instrument panel, right

Fuse / Relay Panel (Left Side Plenum Tray)




Relay location

Auxiliary Relay Panel With Connector Station




Relay location

Auxiliary Relay Panel, Rear




Relay location



97-15585

- E95 = Heat Regulating Switch, Driver Seat
 G60 = Passenger Seat Heater Temperature Sensor
 S12 = Cruise Control / Electronic Thermswitch / Auto Check System / Instrument Cluster / Interior Light With Delay / Back-Up Lights / Servotronic / Automatic Transmission / Airbag Control Light / Coolant Fan Afterrun / Differential Lock / Board Computer, in Fuse Panel
 T5k = Wire Connector, 5 Point, yellow, connector station in auxiliary relay panel
 T6l = Wire Connector, 6 Point, below passenger's seat
 Z8 = Passenger's Seat Heat Element
 Z9 = Passenger's Backrest Heat Element
- 96 - Plus connection (58), in power window / central locking system and door contact switch wiring harness
 A20 - Wire connection (15a), in instrument panel wiring harness
 Q5 - Plus connection (58), in powre window / central locking system and door contact switch wiring harness


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location

- 6** - Heater Fan Relay, J11
- 11** - Coolant FC (Fan Control) Relay, J26

Auxiliary Relay Panel With Connector Station




Relay location

- | |
|---|
| 3 |
| 4 |


 } A/C Compressor Clutch Control Module, J153
- | |
|----|
| 18 |
|----|

 - Third Speed Coolant FC (Fan Control) Relay, J135

Auxiliary Relay Panel, Rear



Relay location




- F18 = Coolant Fan Control (FC) Thermoswitch
- F23 = A/C Refrigerant High Pressure Switch
- F54 = Coolant Fan Control (FC) Thermoswitch
- J11 = Heater Fan Relay
- J26 = Coolant Fan Control (FC) Relay
- J28 = A/C Diode
- J135 = Third Speed Coolant Fan Control (FC) Relay
- N39 = Coolant Fan Control (FC) Series Resistance
- S42 = Fuse For Coolant Fan, in Adapter B
- T5g = Wire Connector, 5 Point, green, connector station in auxiliary panel relay
- T6u = Wire Connector, 6 Point, black, behind instrument panel, left
- T8a = Wire Connector, 8 Point, red, behind instrument panel, center
- V7 = Coolant Fan

(127) - Ground connection -1-, in A/C compressor wiring harness

(L1) - Plus connection (75), in A/C wiring harness

(1) - Ground connection, in battery box

(32) - Ground connection, behind instrument panel, left




97-15574

Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
ll	= violet
ge	= yellow

- F4 = Back-Up Light Switch
- F66 = Engine Coolant Level (ECL) Warning Switch
- F76 = Engine Coolant Temperature (ECT) Electronic Thermoswitch
- F118 = A/C Refrigerant High Pressure Switch
- G3 = Engine Coolant Temperature (ECT) Gauge
- G111 = A/C Compressor Speed Sensor
- J153 = A/C Clutch Control Module
- J189 = Auto Check System
- J192 = MFI Engine Control Module (ECM)
- J201 = Protection Diode
- J217 = Transmission Control Module (TCM)
- J268 = Mini Check System Control Module
- N25 = A/C Clutch
- T1m = Wire Connector, single, red, behind instrument panel, left
- T1n = Wire Connector, single, green, near compressor
- T2z = Wire Connector, double, white, in Plenum, Near Relay Panel (Data Link Connector)
- T2am = Wire Connector, double, green, near compressor

- T5g = Wire Connector, 5 Point, green connector station in auxiliary relay panel
- T5h = Wire Connector, 5 Point, red, behind Instrument panel, left
- T6r = Wire Connector, 6 Point, black, behind Instrument panel, left
- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- (29) - Ground connection, near compressor
- (119) - Ground connection -1-, in headlight wiring harness
- (127) - Ground connection -1-, in A/C compressor wiring harness
- (199) - Ground connection -3-, in Instrument panel wiring harness
- (A45) - Wire connection (RPM signal), in Instrument panel wiring harness
- * - Automatic Transmission only
- K - Wire Distributor For Data Link Connector (DLC); Terminal K




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- E9 = Fresh Air Blower Switch
- E20 = Instrument Panel Light Dimmer Switch
- E30 = A/C Switch
- F38 = Ambient Temperature Switch
- F73 = A/C Refrigerant Low Pressure Switch
- L16 = Fresh Air Control Lever Light
- N24 = Fresh Air Blower Series Resistance With Fuse
- N63 = Fresh Air Recirculating Flap Two-Way Valve
- R = Radio
- T2q = Wire Connector, double, behind instrument panel, left
- T3c = Wire Connector, 3 Point, brown, behind instrument panel, center
- T8a = Wire Connector, 8 Point, red behind instrument panel, center
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- V2 = Fresh Air Blower

- (A34) - Wire connection (75x), in instrument panel wiring harness
- (L13) - Plus connection (75al), in fresh air blower wiring harness

- (81) - Ground connection -1-, in instrument panel wiring harness
- (A19) - Wire connection (58d), in instrument panel wiring harness


Fuse / Relay Panel (Left Side Plenum Tray)



Relay location


- 4 - Headlight Washer System Relay, J39

Auxiliary Relay Panel With Connector Station




Relay location

Auxiliary Relay Panel, Rear




Relay location



Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow


- E1 = Light Switch
- E20 = Instrument Panel Light Dimmer Switch
- F1 = Oil Pressure Switch
- F4 = Back-Up Light Switch
- F22 = Oil Pressure Switch (0,3 bar)
- F66 = Engine Coolant Level (ECL) Warning Switch
- F76 = Engine Coolant Temperature (ECT) Electronic Thermoswitch
- G = Fuel Level Sensor
- G1 = Fuel Gauge
- G3 = Engine Coolant Temperature (ECT) Gauge
- J6 = Voltage Stabilizer
- J268 = Mini Check System Control Module
- S12 = Fuse For Cruise Control / Electronic Thermoswitch / Auto Check System / Instrument Cluster / Interior Light With Delay / Back-Up Lights / Servotronic / Automatic Transmission / Airbag Control Light / Coolant Fan Afterrun / Differential Lock / Board Computer, in Fuse Panel
- S14 = Fuse For License Plate Light / Glove Compartment Light / Engine Compartment Light, in Fuse Panel
- T4h = Wire Connector, 4 Point, black, in engine compartment, right
- T5 = Wire Connector, 5 Point, black, connector station in auxiliary relay panel
- T5c = Wire Connector, 5 Point, on instrument cluster
- T5h = Wire Connector, 5 Point, red, behind instrument panel, left

- T6b = Wire Connector, 6 Point, black, in luggage compartment, left
- T6g = Wire Connector, 6 Point, on instrument cluster
- T6r = Wire Connector, 6 Point, black, behind instrument panel, left
- T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
- T14 = Wire Connector, 14 Point, white, on Mini Check System Control Module
- T26 = Wire Connector, 26 Point, yellow, on instrument cluster
- T26a = Wire Connector, 26 Point, blue, on instrument cluster
- (81) - Ground connection -1-, in instrument panel wiring harness
- (98) - Ground connection, in rear lid wiring harness
- (119) - Ground connection -1-, in headlight wiring harness
- (A7) - Plus connection (58D1), in instrument panel wiring harness
- (A19) - Wire connection (58d), in instrument panel wiring harness
- (A20) - Wire connection (15a), in instrument panel wiring harness
- (A42) - Wire connection (fuel gauge), in instrument panel wiring harness
- * - Manual Transmission Only



- D = Ignition / Starter Switch
 E24 = Seat Belt Switch, Left
 F2 = Door Contact Switch, Left Front
 J39 = Headlight Washer System Relay
 J192 = MFI Engine Control Module (ECM)
 J268 = Mini Check System Control Module
 R = Radio
 S4 = Fuse For Digital Clock / Luggage Compartment Light / Interior Light, Front / Make-Up Mirror Lights / Reading Lights / Cigarette Lighters / Boardcomputer / Automatic Climate Control / Radio / Auto Check System, in Fuse Panel
 T2bc = Wire Connector, double, orange, behind instrument panel, left
 T2bd = Wire Connector, double, black, on Seat Belt Switch, left
 T5a = Wire Connector, 5 Point, brown, connector station in auxiliary relay panel
 T6r = Wire Connector, 6 Point, black, behind instrument panel, left
 T10 = Wire Connector, 10 Point, black, connector station in auxiliary relay panel
 T14 = Wire Connector, 14 Point, white, on Mini check System Control Module
 T26 = Wire Connector, 26 Point, yellow, on instrument cluster
 T26a = Wire Connector, 26 Point, blue, on instrument cluster
 V5 = Windshield Washer Pump

- (81) - Ground connection -1-, in instrument panel wiring harness
 (119) - Ground connection -1-, in headlight wiring harness
 (199) - Ground connection -3-, in instrument panel wiring harness
 (A23) - Wire connection (30al), in instrument panel wiring harness
 (A26) - Wire connection (driver's door contact switch), in instrument panel wiring harness
 (A27) - Wire connection (speed signal), in instrument panel wiring harness
 (A43) - Wire connection (57l), in instrument panel wiring harness
 (A44) - Wire connection (57r), in instrument panel wiring harness
 (A45) - Wire connection (RPM signal), in instrument panel wiring harness
 (A46) - Wire connection (30-from radio), in instrument panel wiring harness




Wiring Color Code	
ws	= white
sw	= black
ro	= red
br	= brown
gn	= green
bl	= blue
gr	= gray
li	= violet
ge	= yellow

- E2 = Turn Signal Switch
- E3 = Emergency Flasher Switch
- E4 = Headlight Dimmer / Flasher Switch
- F = Brake Light Switch
- L1 = Headlight, Left
- L2 = Headlight, Right
- M2 = Tail Light, Right
- M4 = Tail Light, Left
- M6 = Turn Signal Light, Left Rear
- M8 = Turn Signal Light, Right Rear
- M9 = Brake Light, Left
- M10 = Brake Light, Right
- M12 = Side Marker Lights, Rear
- M25 = High Mount Brake Light
- S6 = Fuse For Parking Lights, Side Marker and Tail Lights, Right, in Fuse Panel
- S7 = Fuse For Parking Lights, Side Marker and Tail Lights, Left, in Fuse Panel
- S10 = Fuse For Lowbeam Headlight, Right
- S11 = Fuse For Lowbeam Headlight, Left


- T2an = Wire Connector, double, black, in luggage compartment
- T4 = Wire Connector, 4 Point, near headlight, left
- T4a = Wire Connector, 4 Point, near headlight, right
- T10b = Wire Connector, 10 Point, brown, connector station in auxiliary relay panel
- (50) - Ground connection, in luggage compartment, left
- (119) - Ground connection -1-, in headlight wiring harness
- (A5) - Plus connection (right turn signal), in instrument panel wiring harness
- (A6) - Plus connection (left turn signal), in instrument panel wiring harness
- (A18) - Wire connection (54), in instrument panel wiring harness

Fuse / Relay Panel (Left Side Plenum Tray)



Relay location


Auxiliary Relay Panel With Connector Station




Relay location

- 5 } Power Window / Sunroof Control Module, J139
- 6 }

Auxiliary Relay Panel, Rear



Relay location



97-15576

- E8 = Sunroof Switch
- E56 = Sunroof Stop Switch (Closed Pos.)
- E60 = Sunroof Stop Switch (Raise/Lower)
- F2 = Door Contact Switch, Left Front
- J72 = Sunroof Relay
- J139 = Power Window / Sunroof Control Module
- S83 = Fuse For Sunroof Circuit Breaker, in Adapter C
- T1x = Wire Connector, single, green, behind instrument panel, left
- T2c = Wire Connector, double, white, behind instrument panel, left
- T4k = Wire Connector, 4 Point, black, near sunroof switch
- V1 = Sunroof Motor
- W = Interior Light, Front
- (32) - Ground connection, behind instrument panel left
- (74) - Ground connection, under roof headliner
- (A26) - Wire connection (driver's door contact switch), in instrument panel wiring harness
- * - Installed In Open Relay Position



**We Encourage Professionalism
Through Technician Certification**

W42 WD BOOK AU 04

9/94