

**SECTION INDEX**

A/C HEATER/VENTILATION.....	117
A/C REFRIGERANT CAPACITIES.....	117
ABS/BRAKES.....	120
AIR BAG SYSTEM.....	120
AIR CLEANER.....	124
BACK WINDOW.....	131
CENTER CONSOLE.....	126
CLEAR COAT IDENTIFICATION.....	115
COOLING.....	116
COWL & DASH.....	125
ELECTRICAL.....	124
EMISSION SYSTEM.....	124
ENGINE COVER.....	123
ENGINE OIL COOLER.....	117
ENGINE/TRANS.....	123
ENGINE/TRANS MOUNTS.....	123
EXHAUST.....	124
FRONT BUMPER.....	115
FRONT DOOR.....	128
FRONT DRIVE AXLE.....	122
FRONT FENDER.....	118
FRONT INNER STRUCTURE.....	119
FRONT LAMPS.....	115
FRONT STEERING LINKAGE/GEAR.....	122
FRONT SUSPENSION.....	121
FUEL TANK.....	135
GRILLE.....	115
HOOD.....	116
INFORMATION LABELS.....	115
INSTRUMENT PANEL.....	125
INTERCOOLER.....	117
LIFTGATE.....	133
LUGGAGE LID.....	133
PAINT CODE LOCATION.....	114
QUARTER GLASS.....	133
QUARTER PANEL.....	131
REAR BODY.....	135
REAR BUMPER.....	136
REAR DOOR.....	129
REAR DRIVE AXLE.....	135
REAR LAMPS.....	135
REAR SUSPENSION.....	134
ROCKER/PILLARS/FLOOR.....	127
ROOF.....	130
SEAT.....	127
SEAT BELTS.....	127
SPECIAL CAUTIONS.....	114
STEERING PUMP.....	122
STEERING WHEEL/COLUMN.....	122
SUNROOF.....	131
TURBOCHARGER.....	124
UNDERHOOD DIMENSIONS.....	119
WHEEL.....	120
WINDSHIELD.....	125

**SPECIAL CAUTIONS**

**SUPPLEMENTAL RESTRAINT SYSTEM**

Refer to Procedure Explanation 29 for Supplemental Restraint/Air Bag Special Cautions.

**ABS**

Manufacturer advises that ABS Control Unit be disconnected before welding and removed if a temperature of 85 degrees C (185 degrees F) is to be exceeded for more than 2 hours.

**REFINISH BAKING**

Manufacturer advises that after baking, sufficient cooling time should be allowed before attempting to start vehicle.

**SUSPENSION**

Manufacturer advises that some new fasteners must be used whenever old fasteners are loosened or removed.

**PAINT CODE LOCATION**

Paint code located on luggage compartment floor.