

FRONT SUSPENSION Cont'd

Table listing front suspension parts for 1996-2002 Audi A4/S4. Includes items like 15 Arm Assy, Front Lower Control, 16 Bushing, Otr Control Arm, 17 Bushing, Inr Control Arm, 18 Arm Assy, Rear Lower Control, 19 Bushing, Control Arm, 20 Absorber, Shock, 21 Seat, Spring Lower, 22 Packing, Lower, 23 Cap, Protective, 24 Boot, Dust, 25 Bumper, Spring, 26 Spring, Coil, 27 Seat, Spring Upper, 28 Washer, 29 Mount, Upper, 30 Bar, Stabilizer, 31 Link, Stabilizer, 32 Bushing, Bar.

Table listing front suspension parts for 2000-2002 Audi A4/S4. Includes items like 21 Seat, Spring Lower, 22 Packing, Lower, 23 Cap, Protective, 24 Boot, Dust, 25 Bumper, Spring, 26 Spring, Coil, 27 Seat, Spring Upper, 28 Washer, 29 Mount, Upper, 30 Bar, Stabilizer, 31 Link, Stabilizer, 32 Bushing, Bar.

FRONT DRIVE AXLE

FWD

Table listing front drive axle parts for FWD. Includes R&L Axle Shaft Assy, O/H Axle Shaft Assy, Add to R&L or O/H Axle Shaft Assy, w/Auto Trans.

Illustration Located in Next Column

Table listing front drive axle parts for R&L. Includes 1 Shaft Assy, Axle, 2 Shaft Assy w/Inner Joint, Outer, 3 Boot Kit, Outer, 4 Joint Assy, CV Inner, 5 Boot Kit, Inner, 6 Plate, Attach, 7 Shield, Shaft.




Table listing front drive axle parts for R&L. Includes 4 Joint Assy, CV Inner, 5 Boot Kit, Inner, 6 Shield, Shaft.

AWD QUATTRO

Table listing AWD quattro front drive axle parts. Includes R&L Axle Shaft Assy, O/H Axle Shaft Assy, Add to R&L or O/H Axle Shaft Assy, w/Auto Trans.





Table listing AWD quattro front drive axle parts. Includes 1 Shaft Assy, Axle, 2 Shaft Assy w/Inner Joint, Outer, 3 Boot Kit, Outer, 4 Joint Assy, CV Inner, 5 Boot Kit, Inner, 6 Plate, Attach, 7 Shield, Shaft.

FRONT STEERING LINKAGE/GEAR

Table listing front steering linkage/gear parts. Includes R&L Steering Gear, O/H Steering Gear, NOTE 1: R&L/R&R or O/H Does Not include adjust wheel alignment, NOTE 2: All Parts in this section are included in overhaul unless noted otherwise.

Illustration Located in Next Column

Table listing front steering linkage/gear parts. Includes 1 Gear Assy, Steering.



022-01618

Table listing steering pump parts. Includes New, Remanufactured, 2 Boot, Tie Rod, 3 Clamp, Outer, 4 Clamp, Inner, 5 Ring, Seal, 6 Boot, Damper, 7 Clamp, Boot, 8 Washer, 9 Bracket, 10 Tie Rod Assy, 11 End, Tie Rod, 12 Damper, Steering, 13 Absorber, Sound, 14 Bushing, 15 Boot, Gear, 16 Shield.

Table listing steering pump parts. Includes 2 Boot, Tie Rod, 3 Clamp, Outer, 4 Clamp, Inner, 5 Ring, Seal, 6 Boot, Damper, 7 Clamp, Boot, 8 Washer, 9 Bracket, 10 Tie Rod Assy, 11 End, Tie Rod, 12 Damper, Steering, 13 Absorber, Sound, 14 Bushing, 15 Boot, Gear, 16 Shield.

STEERING PUMP

Illustration Located in Next Column

Table listing steering pump parts. Includes 1 Pump, Steering, 2 Pulley, Pump.