


AUDI A4/S4 1996-02


EXHAUST Cont'd

2.8L ENG Cont'd

AWD (QUATTRO)



FWD




022-01027

AWD Quattro	96-97 8D0 253 409 AF	1.1	386.02
	98-02 8D0 253 409 BE	1.1	386.02
6 Muffler, Rear			
FWD			
1996-98	8D0 253 609 M	.9	337.60
1999			
To VIN X199999	8D0 253 609 M	.9	337.60
From VIN X200001	8D0 253 609 BT	.9	337.60
2000-02	8D0 253 609 BT	.9	337.60
AWD Quattro	8D0 253 609 CB	.9	425.55

EMISSION SYSTEM

1.8L ENG




022-01534

1 Canister, Vapor			
1997-98	8D0 201 801 B	m .9	92.00
1999			
To VIN X199999	8D0 201 801 B	m .9	92.00
From VIN X200001	8D0 201 801 E	m .9	144.25
2000-02	8D0 201 801 E	m .9	144.25
2 Cover, Lower	4A0 201 814 A	m	22.15
3 Hose, Connecting	8D0 133 784	m	18.95
4 Pump, Air			
1997-98	078 906 601 D	m 2.0	249.02
2000			
To VIN Y100000	078 906 601 D	m 2.0	249.02
From VIN Y100001	06A 959 253 B	m 2.0	318.54
2001-02	06A 959 253 B	m 2.0	318.54
5 Bracket, Pump			
1997-99	078 906 615 K		118.50
2000			
To VIN Y100000	078 906 615 K		118.50
From VIN Y100001	8D0 906 615 B		23.15
2001-02	8D0 906 615 B		23.15
6 Pipe, Intake	97-00 058 133 817 H	m	49.50
	01-02 058 133 817 H	m	49.50
7 Pipe, Connecting	058 133 817 D	m	25.20
8 Pipe, Kombi Connecting	058 133 607 D	m	26.25
9 Hose, Angled	058 133 785 B	m	9.20
10 Pipe, Kombi Valve	97-00 058 133 607 E	m	26.25

11 Valve, Combination	01-02 06B 133 607 B	m	26.25
	97-00 058 131 101 B	m #.3	101.75
	01-02 06B 131 101 G	m #.3	113.45
12 Plate, Kombi Valve	97-00 058 131 817	m #.3	26.35
	01-02 06B 131 817 E	m #.3	80.35
#R&R Complete, Includes R&R Gaskets			
13 Gskt, Kombi Valve (2)	078 131 120 K	m	2.25
14 Gskt, Plate	97-00 078 131 120 D	m	1.80
	01-02 078 131 120 M	m	1.10
	N 901 700 01	m	13.95
15 Hose, Kombi Valve			
*Order by Application			
16 Valve, Change-Over	026 906 283 H	m	141.35
17 Sensor, Oxygen			
Before Catalyst	97-02 021 906 265 AQ	m .6	175.62
After Catalyst	97-02 021 906 265 AK	m 1.3	175.62
18 Sensor, Knock	054 905 377 A	m 1.5	63.95
*Order by Application			

2.7L ENG



022-01449


1 Canister, Vapor	8D0 201 801 E	m .9	144.25
2 Cover, Lower	4A0 201 814 A		22.15
3 Hose, Connecting	8D0 133 784	m	18.95
4 Container, Vacuum	443 131 541	m .2	18.90
5 Pump, Air	078 906 601 H	m 2.0	449.33
6 Bumper, Rubber	021 131 085 B		2.45
7 Bracket, Pump	078 906 617 A		11.80
8 Pipe, Kombi Connect	078 131 831 K	m	45.30
9 Valve, Combination	R 078 131 102 E	m #.3	101.75
	L 078 131 101 M	m #.3	101.75
	R/L 078 131 120 K	m #.3	2.25
10 Gskt, Kombi Valve			
#R&R One Side Complete			
11 Adapter, Valve	R 078 131 166 J	m	51.80
	L 078 131 165 F	m	51.80
12 Gskt, Adapter	R 078 131 120 D	m	1.80
	L 078 131 120 E	m	2.25
13 Pipe, Vacuum	R 078 131 492 F	m	63.00
	L 078 131 493 F	m	63.00
14 Connector, Tee	113 201 943 B		1.90
15 Hose, Angle	R/L 026 133 784 E	m	3.75
16 Valve, Change-Over	026 906 283 H	m .5	141.35
17 Pipe, Connecting	078 131 269	m	82.65

2.8L ENG

R&R Both Knock Sensors.....m 2.8

Illustration Located in Next Column

1 Canister, Vapor			
1996-97	8D0 201 803 E	m .9	66.85
1998	8D0 201 801 B	m .9	92.00
1999			
To VIN X199999	8D0 201 801 B	m .9	92.00
From VIN X200001	8D0 201 801 E	m .9	144.25
2000-02	8D0 201 801 E	m .9	144.25
2 Cover, Lower	4A0 201 814 A		22.15
3 Hose, Connecting	8D0 133 784	m	18.95
4 Filter, Carbon-Not Applicable			
5 Pump, Air			
1996-99	078 906 601 D	m 2.0	249.02
2000			
To VIN Y100000	078 906 601 D	m 2.0	249.02
From VIN Y100001	06A 959 253 B	m 2.0	318.54
2001-02	06A 959 253 B	m 2.0	318.54
6 Ring, Pump Protect			
1996-99	078 906 611 A		7.60
2000			
To VIN Y080000	078 906 611 A		7.60
From VIN Y080001	078 906 611 B		3.70
2001-02	078 906 611 B		3.70
7 Cup, Pump			
1996-99	078 906 605 A		83.40
2000			
To VIN Y100000	078 906 605 A		83.40
From VIN Y100001	06A 133 567 B		3.95




046-02071

2001-02	06A 133 567 B		3.95
8 Bracket, Pump			
1996-99	078 906 615 K		118.50
2000-02			
To VIN Y100000	078 906 615 K		118.50
From VIN Y100001	8D0 906 615 B		23.15
2001-02	8D0 906 615 B		23.15
9 Pipe, Intake			
1996-98	078 133 817 E	m	42.25
1999			
To VIN X199999	078 133 817 E	m	42.25
From VIN X200001	078 133 817 P	m	37.85
2000-02	078 133 817 P	m	37.85
10 Pipe, Connector	078 133 889 H	m	39.75
11 Pipe, Kombi Connect	078 131 831 N	m	163.25
12 Valve, Combination	R 078 131 102 F	m #.3	101.75
	L 078 131 101 N	m #.3	101.75
	R/L 078 131 166-5	m #.3	19.20
13 Plate, Kombi Valve			
#R&R One Side Complete, Includes R&R Gaskets			
14 Gskt, Kombi Valve (2/Side)	R/L 078 131 120 K	m	2.25
15 Gasket, Plate	R 078 131 120 D	m	1.80
	L 078 131 120 E	m	2.25
	N.A.	m	0.00
16 Hose, Kombi Valve (3)			
*Cut to Fit			
17 Container, Vacuum	443 131 541	m .2	18.90
18 Brik, Vacuum Container	078 129 814 G		5.55
Valve, EGR	96-97 078 131 503	m	297.25
Sensor, Oxygen			
Before Catalyst	R/L 078 906 265 D	m .4	175.62
After Catalyst	R 078 906 265 J	m .8	170.97
	L 078 906 265 F	m .8	175.62
Sensor, Knock (2)			
1996-98	054 905 377	m 1.5	65.85
1999			
To VIN X260000	054 905 377	m 1.5	65.85
From VIN X260001	078 905 377	m 1.5	38.15
2000-02	078 905 377	m 1.5	38.15
Valve, Electro	054 906 267 A	m	128.85
Valve, Change-Over	026 906 283 H	m	141.35

ELECTRICAL

ALTERNATOR



022-00730

1 Alternator			
1996-98			
1.8L Eng	058 903 018 C	m 1.0	800.00
2.8L Eng			
New	078 903 015 FX	m 2.3	R551.15
Remanufactured	078 903 015 FX	m 2.3	R551.15
1999-02			
1.8L Eng			
90 Amp	038 903 018 E	m 1.0	693.98
120 Amp	038 903 018 F	m 1.0	693.98